ARM PROGRAMMING

Bùi Quốc Bảo

Standard malloc and free function


- They are not always available on small embedded systems.
- Their implementation can be relatively large so take up valuable code space.
- They are rarely thread safe.
- They are not deterministic. The amount of time taken to execute the functions will differ from call to call.
- They can suffer from memory fragmentation.
- They can complicate the linker configuration.

FreeRTOS pvPortMalloc() and vPortFree()


- FreeRTOS cung cấp 2 hàm pvPortMalloc() và pvPortFree()
- User có thể viết lại hai hàm này
- Hai hàm này nằm trong các file heap_1.c, heap_2.c and heap_3.c, trong thư mục
 FreeRTOS\Source\Portable\MemMang

Heap_1.c

- Heap1.c cung cấp một hàm pvPortMalloc() cơ bản, không có hàm pvPortFree()
- Các chương trình mà không có lệnh xóa task, semaphore, queue thì có thể dùng heap1.c



Heap1.c cung cấp hàm pvPortMalloc() và pvPortFree()



Heap3.c

 Heap3.c dùng các hàm malloc và free, đồng thời suspend scheduler

```
void *pvPortMalloc( size_t xWantedSize )
{
  void *pvReturn;

  vTaskSuspendAll();
  {
    pvReturn = malloc( xWantedSize );
  }
  xTaskResumeAll();
  return pvReturn;
}
```

```
void vPortFree( void *pv )
{
   if( pv != NULL )
   {
     vTaskSuspendAll();
     {
        free( pv );
     }
     xTaskResumeAll();
   }
}
```