

RED SEAL EXAM PREP

442A Industrial Electrician

Free 50-Question Mock Exam

Practice for the Red Seal / Certificate of Qualification exam

Pass mark: 70% · Grouped by this site's own topic areas
<https://redsealquiz.ca> · Edition October 2026

About This Material

Independent, unofficial study resource. This publication is not affiliated with, endorsed by, or approved by the Canadian Council of Directors of Apprenticeship (CCDA), Employment and Social Development Canada, the Red Seal Program, Skilled Trades Ontario, or any provincial or territorial apprenticeship authority. "Red Seal" is used solely to describe the examination for which this material provides practice.

Originality. All questions and explanations in this publication are original works created by the author. The topic areas are this publication's own grouping and are not one-to-one with the official Major Work Activities; the official exam breakdown for each trade is published at red-seal.ca. This material reproduces no content from any actual examination.

No guarantee of results. This study material is provided for educational and informational purposes only. Success on any certification examination depends on many factors, and no representation is made that using this material will result in passing any exam. Exam content, structure, and weightings are set by certification authorities and may change without notice.

Technical accuracy. Code values and technical specifications cited in explanations reflect commonly referenced Canadian standards at the time of writing. Always defer to the current edition of the applicable code or the manufacturer's documentation in real work.

Updates. Corrections are published to the same file. Download it again from redsealquiz.ca to get the current edition.

Questions or a correction? lidbil515@gmail.com

© 2026 the author. All rights reserved. Free for personal study use. Please share the link to redsealquiz.ca rather than the file; resale is prohibited.

Mock Exam — answer all questions, then check the key

Q1. What is a VFD (Variable Frequency Drive)?

- A) An electronic device that varies supply frequency and voltage
- B) A device that varies the motor supply voltage to control speed
- C) A device that controls motor torque only
- D) A mechanical gear reducer for motor speed control

Q2. Under CEC Section 18, which wiring method is acceptable in a Class I, Zone 1 (formerly Division 1) hazardous location?

- A) Threaded rigid metal conduit with flameproof fittings
- B) Rigid PVC conduit with ordinary solvent-weld couplings
- C) Electrical metallic tubing with set-screw couplings
- D) NMD90 non-metallic sheathed cable stapled to framing

Q3. What is an active harmonic filter?

- A) A passive LC trap tuned to shunt a single harmonic order, most often the fifth harmonic
- B) A capacitor bank switched in only to correct displacement power factor at the main bus
- C) An electronic unit that injects counter-harmonic current in real time to cancel harmonics
- D) A series line reactor that limits harmonic current by adding impedance ahead of the drive

Q4. A 442A electrician finds a 3-phase induction motor drawing Phase A=28A, Phase B=31A, Phase C=24A while running unloaded at rated voltage. What is the MOST likely cause?

- A) Voltage unbalance at the supply terminals
- B) Worn motor bearings causing mechanical drag
- C) Single-phasing from a blown control fuse
- D) Motor is overloaded beyond nameplate rating

Q5. What is the function of a contactor in a motor starter?

- A) To protect the motor from sustained overcurrent by opening the circuit on a thermal overload
- B) To make and break the motor power circuit under load
- C) To convert a single-phase supply into balanced three-phase power for the motor windings
- D) To monitor motor speed and continuously adjust the applied voltage to hold that speed steady

Q6. What is a timer instruction in PLC ladder logic?

- A) An instruction that restarts the processor after a set time
- B) An instruction that changes a done bit at a preset time
- C) A network module that synchronizes the clocks of several PLCs
- D) A hardware clock module that sequences machine operations

Q7. What is slip in an induction motor?

- A) The mechanical efficiency of the motor
- B) The difference between rated and measured voltage
- C) The difference between synchronous and rotor speed
- D) The starting current relative to full-load current

Q8. What is a delta-wye (Δ -Y) transformer connection and what is its advantage?

- A) Wye primary reduces short circuit current; Delta secondary increases voltage
- B) The wye secondary provides a grounded neutral
- C) Both delta and wye are identical in performance
- D) Delta is for HV primary; Wye is only for motor loads

Q9. What is a normally open (NO) contact in PLC ladder logic?

- A) A contact used only in emergency stop circuits
- B) A contact that passes logic when its reference bit is TRUE
- C) A contact that passes current only when its coil is de-energized
- D) A physical contact that is open by default in the field

Q10. What is a differential pressure (DP) transmitter used for?

- A) To measure absolute pressure in a vessel
- B) To control the differential pressure in a boiler
- C) To measure flow or level by sensing a pressure difference
- D) To measure the voltage difference between two phases

Q11. What is the difference between a "fail open" (FO) and "fail closed" (FC) control valve?

- A) FO opens at full stroke; FC closes at full stroke
- B) FO is for liquid service; FC is for gas service
- C) FO uses a butterfly valve; FC uses a globe valve
- D) FO opens on loss of air/power; FC closes on loss

Q12. An RTD (Pt100) temperature sensor reads -40°C in an oven that is clearly at room temperature ($\sim 22^{\circ}\text{C}$).

A technician measures approximately $84\ \Omega$ at the RTD terminals at the DCS. What is the MOST likely fault?

- A) The DCS analog card has failed
- B) RTD element has failed open
- C) RTD calibration drift from overheating
- D) RTD extension wires are partially shorted

Q13. A 442A electrician is performing work on a 600V motor control center (MCC). CSA Z462 requires establishment of an electrically safe work condition. In the correct sequence, what is the THIRD step?

- A) Verify absence of voltage with a properly rated test instrument
- B) Release or restrain stored energy (capacitors, springs)
- C) Apply lockout/tagout devices to all energy isolation points
- D) Visually verify that each disconnecting device is open

Q14. Switchgear feeding a large pump motor has been replaced. A phase rotation tester at the motor starter reads the same A-B-C sequence as before the work. Why must the motor still be bumped and the shaft direction observed before the pump goes back into service?

- A) Because the tester reads sequence only above the motor's rated voltage
- B) Because the supply sequence alone does not fix which way the shaft turns
- C) Because bumping is the only way to confirm the overload is sized right
- D) Because a rotation tester cannot read the sequence on a loaded circuit

Q15. What is the purpose of a power factor correction capacitor bank?

- A) To regulate voltage at the service entrance
- B) To filter voltage harmonics from VFDs
- C) To supply reactive power locally
- D) To store energy for emergency power

Q16. What is a motor's breakdown torque?

- A) The maximum torque the motor can develop at rated voltage
- B) The torque the motor produces at zero speed in the instant the contactor first closes
- C) The torque loading at which the stator windings overheat and burn out under sustained overload
- D) The torque delivered continuously at nameplate full load speed and rated nameplate current

Q17. Before touching conductors that have been isolated and locked out, a worker tests for absence of voltage. Why must the tester be proved on a known live source both before and after that test?

- A) To prove that the tester itself was working when it read zero
- B) To confirm the tester is set to the correct voltage range first
- C) To satisfy the requirement that two workers witness the test
- D) To discharge any stored charge left in the tester's own leads

Q18. What is a control valve Cv (flow coefficient)?

- A) The valve stroke in percentage per volt of signal
- B) The valve's closing velocity in m/s
- C) The valve's flow capacity at 1 psi pressure drop
- D) The calibration verification number of the valve

Q19. What is the HART protocol and what is its primary advantage?

- A) Hardwired Addressable Relay Technology — a relay-based hardwired interlock scheme
- B) High-speed Analog Real-Time Transmission — faster than a standard 4-20 mA loop
- C) A fibre-optic link that replaces the 4-20 mA loop between field and control room
- D) Highway Addressable Remote Transducer — digital data on the same 4-20 mA loop

Q20. What is OPC-UA in industrial automation?

- A) OPC Unified Architecture — an open data exchange standard
- B) A proprietary programming language that runs only on Siemens S7 series controllers
- C) Optimal Power Control — Utility Automation, a plant demand management scheme
- D) Override Process Control — Universal Application, a manual DCS override mode

Q21. What is the difference between AC and DC electricity?

- A) AC reverses direction periodically; DC flows one way
- B) AC is only for power transmission; DC is for motors
- C) DC is safer than AC for all applications
- D) AC always has higher voltage than DC

Q22. What personal protective equipment is required for energized work on 600 V equipment?

- A) No PPE is needed at 600 V, which is low voltage
- B) Leather work gloves and a hard hat are enough
- C) Safety glasses and CSA-approved work boots only
- D) Arc-rated PPE with insulated gloves and tools

Q23. A delta-delta bank of three identical 50 kVA single-phase transformers supplies a plant. One transformer fails and is disconnected, and the bank is reconnected open delta on the two remaining units. What is the largest balanced three-phase load, in kVA, that the open-delta bank can carry without overloading either transformer?

- A) 129.9 kVA
- B) 75.0 kVA
- C) 86.6 kVA
- D) 100.0 kVA

Q24. A wound-rotor induction motor is connected with external resistance in the rotor circuit. After the resistance is short-circuited, motor RPM increases from 1,680 to 1,740 under the same load. What does this confirm?

- A) The motor had a shorted stator winding
- B) Synchronous speed of this motor is 1,740 RPM
- C) External resistance was increasing slip and reducing speed
- D) The motor was single-phasing before the resistance change

Q25. What is motor efficiency and what does IE3 mean?

- A) IE3 = 3-phase efficiency; efficiency refers to power factor only
- B) IE3 = Premium Efficiency; efficiency = mechanical output / electrical input
- C) IE3 = third generation motor; efficiency is ratio of mechanical output to electrical input
- D) IE3 = insulation class; efficiency is ratio of torque to speed

Q26. What is the purpose of a distribution transformer in an industrial facility?

- A) To step down supply voltage to utilization voltage
- B) To filter the harmonic currents produced by the plant's variable frequency drives
- C) To correct the plant's overall power factor and reduce the utility demand charge
- D) To generate electrical power on site to carry the plant through a utility outage

Q27. What is program scan time and why does it matter in safety-critical applications?

- A) The time between scheduled PLC maintenance — longer scan = more wear
- B) The time for the PLC to boot after power loss
- C) The time for one complete scan cycle — limits response speed
- D) The time for the PLC to communicate with the HMI

Q28. Two jobs are planned on the same 600V system: one beside an exposed fixed circuit part inside a switchboard, the other beneath an exposed movable overhead conductor. How do the CSA Z462 limited approach boundaries for the two jobs compare?

- A) The movable conductor job has the larger limited approach boundary
- B) The fixed circuit part job has the larger limited approach boundary
- C) Both jobs share one limited approach boundary set by voltage alone
- D) Limited approach boundaries begin only above 750 volts to ground

Q29. What does FLA or FLC stand for on a motor nameplate?

- A) Full Line Ampacity
- B) Frequency Limit Adjustment
- C) Full Load Amperes
- D) Fuse Load Allowance

Q30. What is the formula for three-phase power?

- A) $P = V \times I$ (same as single phase)
- B) $P = \sqrt{3} \times V_L \times I_L \times PF$ (line values)
- C) $P = V_L \times I_L / \sqrt{3}$
- D) $P = 3 \times V \times I \times PF$ (where V = line voltage)

Q31. A 600 V switchboard has a nameplate rating below 1200 A and no draw-out parts. What minimum working space does the CEC require in front of it?

- A) 600 mm (24 in)
- B) 1.0 m (39 in)
- C) 1.5 m (60 in)
- D) 900 mm (36 in)

Q32. What is a short circuit current rating (SCCR) and why is it important for industrial panels?

- A) The minimum current needed for the circuit to operate
- B) The overcurrent protection setting for the main breaker
- C) The panel's maximum continuous load current rating
- D) The maximum fault current a panel can safely withstand

Q33. A technician uses a clamp meter to measure current on a 3-phase motor with star (Y) connection. Each phase measures 18A. What is the line current feeding this motor?

- A) 54A (18×3)
- B) 18A (line = phase)
- C) 31.2A ($18 \times \sqrt{3}$)
- D) 10.4A ($18 / \sqrt{3}$)

Q34. What is a ground fault circuit interrupter (GFCI) and where is it required?

- A) A device that protects branch circuit conductors from sustained overload and thermal damage
- B) A device that limits the arc-flash incident energy released at the panel during a fault
- C) A fuse element that clears bolted short circuits and high-current faults only
- D) A device that opens the circuit on a ground-fault imbalance of about 6 mA

Q35. A technician is troubleshooting a PLC-controlled system. The physical motor runs but the PLC output LED is OFF. The motor starter coil is confirmed energized from an external source. What does this indicate?

- A) The processor is in run mode but the scan is halted
- B) The status LED on the output module is defective
- C) The motor is fed through a bypass, not by the PLC
- D) The output module has failed and must be replaced

Q36. A 442A electrician measures a single-phase 120V AC circuit drawing 15A with a power factor of 0.75 lagging. What is the true (real) power consumed?

- A) 1,800 W
- B) 1,190 W
- C) 2,400 W
- D) 1,350 W

Q37. What is the purpose of a safety relay or safety PLC?

- A) To supply backup control power so the machine keeps running when the main PLC loses supply
- B) To protect the PLC input and output cards from voltage spikes and inductive switching transients
- C) To automatically reset and restart the machine as soon as the emergency stop button is pulled out
- D) To monitor safety functions and force a safe state on fault

Q38. What is the difference between a TEFC and ODP motor enclosure?

- A) TEFC is for DC motors; ODP is for AC motors
- B) TEFC is explosion-proof; ODP is for outdoor use
- C) TEFC is sealed and fan cooled; ODP has ventilation openings
- D) They are interchangeable — enclosure type has no practical significance

Q39. What is an equipotential bonding mat used for in industrial work?

- A) To protect workers from step and touch potential
- B) To bond the conduit and raceway system back to the driven ground electrode at the service entrance
- C) To measure the resistance of bonding conductors and the ground grid during commissioning tests
- D) To provide a clean insulated surface for storing rubber gloves and live-line tools between tasks

Q40. What is the role of a motor nameplate?

- A) To specify the bearing lubrication intervals and the preventive maintenance schedule
- B) To provide rated data for installation and protection
- C) To display the manufacturer's brand and catalogue number for identification purposes only
- D) To record the warranty period and the serial number needed when filing a claim

Q41. A Type J thermocouple is installed in a furnace. The DCS reads about 305°C while a calibrated RTD reference beside it shows 230°C. The error is high, repeatable, and grows as the furnace heats up. What is the MOST likely cause?

- A) Ambient temperature at the terminal block is high and is being added on top of the process reading
- B) The thermocouple is installed with reversed polarity, which doubles the millivolt signal reaching the controller
- C) The thermocouple extension wire has an open break in the run, which adds a fixed error to the reading
- D) The controller is configured for Type K instead of Type J thermocouple

Q42. What is a 2-wire vs 4-wire transmitter?

- A) 2-wire transmitters are for digital signals; 4-wire for analog
- B) 2-wire is loop-powered; 4-wire has a separate power supply
- C) Wire count refers to the number of calibration points only
- D) 2-wire = only positive terminal; 4-wire = both terminals

Q43. What happens if a current transformer (CT) secondary is open-circuited while the primary is energized?

- A) The primary current collapses toward zero because the transformer's magnetic circuit is broken
- B) Dangerously high voltage appears on the secondary
- C) The loss of secondary current is detected and the protective relay trips the feeder offline
- D) Nothing hazardous happens — the CT simply stops producing an output until it is reconnected

Q44. A technician performs a voltage drop test on a 120V, 20A branch circuit supplying a load 50m from the panel. The voltage drop measured is 8V (6.7%). What corrective action should be taken per CEC requirements?

- A) Add a voltage regulator at the load end
- B) Replace the load with a lower-power model
- C) No action needed — CEC allows 10% drop
- D) Increase the conductor size for the run

Q45. What is impedance (Z) in AC circuits?

- A) The maximum instantaneous current an AC circuit can carry when it is driven at resonance
- B) The phase angle in degrees by which the current waveform lags or leads the applied voltage
- C) The purely resistive component of the circuit, which an ohmmeter reads directly across the load
- D) The total opposition to current flow in an AC circuit

Q46. What is the purpose of a star-delta (Y-Δ) starter?

- A) To step up voltage for high-voltage motor starting
- B) To reduce starting current by starting in star, then switching to delta
- C) To allow the motor to run in both clockwise and counterclockwise directions
- D) To vary motor speed by changing the number of poles

Q47. What is the purpose of a motor's thermal protection (thermistor or thermostat)?

- A) To measure motor frame vibration
- B) To measure motor shaft speed
- C) To protect against phase loss only
- D) To directly sense winding temperature

Q48. A 4-20mA loop-powered transmitter reads 3.6mA with the process at 0% (minimum range). What does this indicate and what should the technician do FIRST?

- A) Transmitter fault — verify loop supply and zero trim
- B) Broken signal wire — replace immediately
- C) Normal — some transmitters operate below 4mA at process zero
- D) PLC analog input card has failed

Q49. What is Ohm's Law?

- A) $V = I \times R$
- B) $P = I \times R$
- C) $R = V \times I$
- D) $I = V \times R$

Q50. What is an E-stop (emergency stop) circuit and why must it be hardwired?

- A) A hardwired circuit that removes power regardless of PLC state
- B) A normally open contact wired in parallel with the start button
- C) A software command in the PLC program that stops the motors
- D) A wireless emergency stop button linked to the PLC by radio

Answer Key & Explanations

Scoring: 35 correct out of 50 is 70%. These 50 questions come from the 130-question 442A bank; [the last page](#) shows what the complete printable bank contains.

Q1. Answer: A

A VFD converts fixed AC to variable frequency and voltage AC, allowing precise motor speed control. Speed is proportional to frequency ($n = 120f/P$). Also called variable speed drive (VSD) or adjustable frequency drive (AFD).

Q2. Answer: A

A Zone 1 location can hold an explosive gas atmosphere during normal operation, so the wiring must neither become a source of ignition nor let an ignition inside the system propagate out to the surrounding atmosphere. Threaded rigid metal conduit with flameproof (explosion-proof) fittings does both: the long threaded joints act as flame paths that cool escaping gases below the ignition temperature of the atmosphere outside. The other Zone 1 method used every day in Canadian plants is hazardous-location certified cable, such as HL-marked Teck 90 terminated in certified cable glands. Set-screw tubing, solvent-welded PVC and non-metallic sheathed cable offer no flame path and no certified gland, so none of them is acceptable.

Q3. Answer: C

VFDs, UPS systems and other non-linear loads draw current in pulses rather than sinusoidally, injecting harmonic currents that distort the bus voltage, overheat neutrals and transformers, and nuisance-trip sensitive equipment. An active harmonic filter measures the load current, works out its harmonic content, and injects an equal and opposite current in real time, so cancellation happens across a broad band instead of at one tuned frequency. Passive mitigation — line reactors, DC link chokes and tuned LC traps — does reduce harmonics, but it cannot adapt as the load changes.

Q4. Answer: A

A small voltage unbalance shows up as a much larger current unbalance. Current unbalance runs roughly 6 to 10 times the voltage unbalance, on a percent basis. These three readings average 27.7A and the worst phase (the 24A phase) is about 3.7A off that average, so the current unbalance is about 13% - which points back to a voltage unbalance of only about 1 to 2% at the supply, small enough to be missed unless the line voltages are actually measured. Worn bearings cause noise and drag but do not unbalance the phase currents. Single-phasing would show one phase near zero. A genuine overload raises all three phases together, and this motor is running unloaded.

Q5. Answer: B

A contactor is a heavy-duty, magnetically operated switch with large contacts rated to make and break load current repeatedly. It is the power-switching component of a motor starter.

Q6. Answer: B

Timer instructions count elapsed time against a preset value, and each type drives its done bit differently. A TON, timer on-delay, sets its done bit once the accumulated time reaches the preset while the rung stays true. A TOF, timer off-delay, sets its done bit as soon as the rung goes true and resets it once the accumulated time reaches the preset after the rung goes false - nothing is set at the preset. An RTO, retentive timer, keeps its accumulated time when the rung goes false and must be cleared with a RES instruction. Timers are used for timed sequences, delay functions and time-based control.

Q7. Answer: C

Slip is expressed as a percentage: $\text{Slip} = (N_s - N_r) / N_s \times 100\%$. At no load, slip is small. At full load, typical slip is 2–5%. Slip allows the rotor conductors to experience a changing magnetic field, inducing the rotor current that creates torque.

Q8. Answer: B

A delta-wye transformer has the primary wound in delta, with no neutral, and the secondary wound in wye with a neutral point that is grounded. That gives a 4-wire secondary carrying both the three-phase line-to-line voltage (for example 600 V) and a line-to-neutral voltage (347 V, since $600/\sqrt{3} = 346.4$), so single-phase loads and the system ground reference are taken from the same transformer. Wrong answers: a wye primary does not reduce short-circuit current and a delta secondary does not raise voltage — available fault current is set by the supply impedance and by the transformer's impedance and turns ratio, not by the winding configuration; a wye secondary is not restricted to motor loads, since its whole value is that it also supplies line-to-neutral single-phase loads; and the two connections are not identical in performance, because only the wye secondary offers a neutral. For contrast, a wye-delta bank places the neutral on the primary side only and leaves a three-wire secondary with no neutral, while a delta-delta bank has no neutral on either side. The delta winding also gives triplen harmonic currents a path to circulate, keeping them out of the other winding. Red Seal point: 600 V/347 V systems in Canada use delta-wye transformers so that 347 V single-phase lighting branch circuits can be supplied from the same transformer as 600 V three-phase motor loads.

Q9. Answer: B

In ladder logic, a NO contact (XIC instruction in Allen-Bradley) allows rung continuity when the corresponding bit in memory is 1 (TRUE). It represents the state when the associated coil or input is energized.

Q10. Answer: C

DP transmitters measure the difference between two pressure taps. With an orifice plate restriction, DP indicates flow (square root relationship). For level measurement, DP corresponds to liquid column height $\times$ density.

Q11. Answer: D

Fail-safe position is determined by process safety analysis. Fail open (FO): the spring pushes the valve open on loss of instrument air (e.g., cooling water valves must stay open on failure). Fail closed (FC): the spring closes the valve (e.g., fuel gas valves must close on failure).

Q12. Answer: D

A shorted RTD lead appears as lower resistance than actual temperature. A short circuit somewhere in the 3-wire RTD extension leads reduces measured resistance below actual, making the DCS calculate a lower (incorrect) temperature. Pt100 at 22°C $\approx$ 108.6 Ω , but at -40°C it is 84.27 Ω (IEC 60751) — the ~84 Ω measured means a partial short in the leads is bypassing ~25 Ω of the element's true resistance, so the DCS computes -40°C.

Q13. Answer: D

CSA Z462 sets out the sequence for establishing an electrically safe work condition: 1) Determine all possible sources of supply. 2) Open the disconnecting device for each source. 3) Visually verify that each disconnecting device is open, withdrawing draw-out breakers where used. 4) Release or block any stored energy. 5) Apply lockout/tagout devices. 6) Verify absence of voltage with an adequately rated test instrument. The third step is therefore the eyes-on check that the disconnects have actually opened — a handle can move without the contacts parting. Testing for absence of voltage is a different action performed last, at each point of work, after the locks are already on. Do not read the step-3 visual check as proof that the circuit is dead; only the live-dead-live instrument test establishes that.

Q14. Answer: B

A sequence test proves what the supply is doing, not what the shaft will do. A phase rotation tester tells you the order in which the three supply phases reach their peaks at the point where you clipped on. Confirming that after switchgear work is worth doing, because a reversed supply sequence would reverse every motor on the bus at once. But it says nothing about which way one particular shaft turns, and that depends on three more things the tester never sees: how the motor leads were landed in the terminal box, how the winding was connected internally if the motor has been rewound, and whether a coupling or gearbox between motor and pump reverses direction. Only watching the shaft during a momentary bump settles it. The stakes are that a centrifugal pump run backwards still moves some liquid and can look plausible on a flow indicator, so the error survives long enough to do damage. Rotation testers work at normal system voltage and do not need the circuit unloaded, and overload sizing comes from the nameplate full-load current, not from a bump.

Q15. Answer: C

Inductive loads (motors, transformers) draw reactive power (kVAR) from the utility. Capacitor banks supply this reactive power locally, reducing the reactive current drawn through supply cables, improving power factor, and reducing utility demand charges and penalties.

Q16. Answer: A

Breakdown torque (pull-out torque) is the maximum torque an induction motor can develop at rated voltage before speed drops into an unstable region. If load exceeds this value, the motor stalls. Typically 200–300% of full-load torque.

Q17. Answer: A

A voltage tester that has failed reads zero on a live conductor exactly as it reads zero on a dead one. A blown fuse, a broken lead, a flat battery, a damaged range switch - none of them announce themselves, and every one of them turns the instrument into a device that says 'safe' about everything. Proving the tester on a known live source immediately before the absence-of-voltage test, taking the test, then proving it again on the known live source afterwards is what establishes that the zero reading meant the conductors were dead rather than that the instrument was dead. The second proving matters as much as the first, because an instrument can fail during the test. This live-dead-live check is a step in establishing an electrically safe work condition, after the disconnecting devices have been opened, locked out and visually verified. Selecting the right range matters but detects nothing about a failed instrument, nothing needs discharging from the leads, and a second person watching does not verify the meter.

Q18. Answer: C

Cv is the flow capacity of a valve — the volume of water (US gallons per minute) that flows through it with a 1 psi pressure drop. Sizing: $C_v = Q \times \sqrt{(SG/\Delta P)}$ where Q is flow in gpm, SG is specific gravity, ΔP is pressure drop in psi. Larger Cv = larger flow capacity.

Q19. Answer: D

HART (Highway Addressable Remote Transducer) superimposes a digital frequency-shift-keyed signal — roughly ± 0.5 mA at the 1200 Hz and 2200 Hz Bell 202 tones — on top of the 4–20 mA loop current. Because the modulation averages to zero, the analog measurement keeps controlling the process while a handheld communicator or an asset-management system reads and writes configuration, runs diagnostics and pulls secondary variables over the same two wires. That is the advantage: digital access with no additional wiring and no disturbance to the analog control signal. Wrong answers: HART is not a faster substitute for the analog loop — the digital channel is deliberately slow, which is why it is used for configuration and diagnostics rather than for closed-loop control; it is not a fibre-optic control-room network, and it does not replace the 4–20 mA loop, it rides on it; and the acronym does not stand for a relay interlock scheme.

Q20. Answer: A

OPC-UA (OPC Unified Architecture) is an open, platform-independent, secure data exchange standard for industrial automation. It enables interoperability between different vendor systems, PLCs, SCADA, and cloud platforms.

Q21. Answer: A

AC (alternating current) reverses polarity/direction at the supply frequency (60 Hz in North America = 120 reversals/second). DC (direct current) flows in one constant direction only. AC is used for power distribution; DC for electronics, batteries, and VFD internal circuits.

Q22. Answer: D

Energized work on a 600 V industrial system can produce a severe arc flash. Under CSA Z462 the protection is chosen one of two ways, and the two must not be mixed: either an incident-energy analysis is done and the arc rating of the clothing and equipment must equal or exceed the incident energy calculated for that task, or the arc-flash PPE tables in Z462 are used and the clothing must meet the minimum arc rating those tables specify for that task on that equipment. Either route ends in the same kit - arc-rated clothing with a face shield or an arc-rated hood, rubber insulating gloves with leather protectors rated for the system voltage, and insulated tools. Energized work also requires a documented justification for not de-energizing and an energized-work permit.

Q23. Answer: C

An open-delta (V) bank is rated at the square root of 3 times the kVA of one unit: $1.732 \times 50 = 86.6$ kVA. In the V connection each remaining winding sits directly in series with a line, so it carries the full line current at the full line voltage. With each winding held to its 50 kVA rating, the three-phase output is the square root of $3 \times \text{line voltage} \times \text{line current} = 1.732 \times 50 = 86.6$ kVA, against $3 \times 50 = 150$ kVA for the closed bank - the bank keeps 57.7% (1 divided by the square root of 3) of its original rating. At that load each unit carries rated current at rated voltage, so each is at 100% of its own nameplate, yet the two units together yield only 86.6 kVA of their combined 100 kVA nameplate: the current in each winding is displaced 30 degrees from that winding's voltage, and $\cos 30 \text{ degrees} = 0.866$, so the two kVA ratings do not add arithmetically. 100 kVA is therefore the survivors' nameplate sum, which would put 57.7 kVA on each 50 kVA winding (115%). 129.9 kVA applies the 86.6% figure to the wrong base - the original 150 kVA bank instead of the two survivors. 75 kVA comes from stacking both derating factors ($150 \times 0.577 \times 0.866$), or from assuming the loss simply halves the bank. If the original 150 kVA load is left connected, each unit carries about 173% of rated current (150 divided by 86.6), which is why open delta is an emergency measure: cut the load to 86.6 kVA until the third unit is replaced.

Q24. Answer: C

External rotor resistance increases slip, reducing speed. Wound-rotor motors use external resistance to limit starting current and control speed. When resistance is removed (short-circuited) for normal operation, slip decreases and speed approaches synchronous speed. 1,800 RPM synchronous at 60 Hz for a 4-pole motor; 1,740 RPM represents normal running slip.

Q25. Answer: B

Motor efficiency = $(\text{output HP} \times 746) / (\text{input watts}) \times 100\%$. IEC 60034-30 defines efficiency classes: IE1 (standard), IE2 (high), IE3 (premium), IE4 (super premium). IE3 is required for most motors in Canada under energy efficiency regulations.

Q26. Answer: A

Distribution transformers step down the high-voltage utility supply (e.g., 13.8 kV) to the utilization voltages used by plant equipment. Common industrial: 13.8 kV $\rightarrow$ 600V for large motors/feeders, 600V $\rightarrow$ 120/208V for lighting and controls.

Q27. Answer: C

Scan time — the duration of one complete read-execute-write cycle — determines how quickly the PLC and its control loop respond to process changes. In safety applications, if the scan time is too long, a hazardous condition may persist for longer than acceptable. Safety PLCs have deterministic, certified scan times.

Q28. Answer: A

CSA Z462 tabulates approach boundaries by system voltage band, and inside each band it lists two different limited approach distances: a larger one for exposed movable conductors and a smaller one for exposed fixed circuit parts. A movable conductor can swing, sag or be dragged toward a worker, so the standard keeps people further back from it. Voltage alone therefore does not settle the boundary — the worker must also establish whether the exposed live part is fixed or movable. The limited approach boundary is the line an unqualified person may not cross unless advised of the hazard and escorted by a qualified person, and it applies at 600V just as it does at higher voltages.

Q29. Answer: C

FLA (Full Load Amperes) or FLC (Full Load Current) is the motor's rated current drawn at nameplate voltage and full mechanical load. Used for sizing conductors, overload protection, and motor starter components.

Q30. Answer: B

Three-phase real power: $P = \sqrt{3} \times V_L \times I_L \times \cos\theta$. Where V_L = line-to-line voltage, I_L = line current, $\cos\theta$ = power factor. This applies to balanced 3-phase systems.

Q31. Answer: B

Rule 2-308(1) calls for a minimum working space of 1 m with secure footing in front of electrical equipment such as switchboards, panelboards, control panels and motor control centres, and that space is kept clear of obstructions. The step up to 1.5 m comes from Rule 2-310(2), and it follows the equipment nameplate rating rather than the overcurrent setting: it applies where the board is rated 1200 A or more, or over 750 V, and a person inside the electrical room or the space around the equipment could not leave without passing a potential failure point on the path to the exit. A 600 V board rated below 1200 A meets neither of those ratings, so the 1 m figure stands. Equipment that has draw-out parts adds the depth of those parts on top of whichever figure applies, which is why the question rules them out. The trap option 900 mm (36 in) is the working-clearance figure from US NEC 110.26, whereas the Canadian minimum in front of this switchboard, set by Rule 2-308(1), is 1 m (39 in).

Q32. Answer: D

SCCR is the maximum prospective fault current an electrical assembly — a panel, MCC or drive — can withstand without damage beyond acceptable limits. It is a withstand rating belonging to the assembly and its non-protective components, and it is distinct from the interrupting rating (AIC) of the fuses or breakers inside it, which is the fault current those protective devices can themselves safely clear. Both matter and they are specified separately: the assembly has to be rated for at least the available fault current at the point of installation, and the overcurrent device has to be able to interrupt it. An under-rated assembly can rupture busbars and blow open its enclosure instead of letting the fault be cleared cleanly.

Q33. Answer: B

In a star (Y) connected motor, line current equals phase current. In Y connection: $I_{\text{line}} = I_{\text{phase}} = 18\text{A}$. Only voltage differs: $V_{\text{line}} = V_{\text{phase}} \times \sqrt{3}$. This is opposite to delta: in delta, $I_{\text{line}} = I_{\text{phase}} \times \sqrt{3}$, but $V_{\text{line}} = V_{\text{phase}}$. The clamp meter on each supply line will read 18A.

Q34. Answer: D

A GFCI compares the current leaving on the ungrounded conductor with the current returning on the neutral; any difference is going to ground, possibly through a person. A Class A device must interrupt the circuit when that imbalance is 6 mA or more, and must not interrupt it when the imbalance is 4 mA or less. That is why a GFCI protects people while a fuse or breaker, sized to protect the conductor, will never open at milliamp levels. The threshold and the trip time are two separate specifications: the maximum permitted trip time is an inverse curve, several seconds at the 6 mA threshold and only about 20 ms once the fault current passes a few hundred milliamps. In Ontario, Rule 26-704 requires Class A GFCI protection for 5-15R and 5-20R receptacles installed outdoors within 2.5 m of finished grade, including block-heater receptacles in parking lots.

Q35. Answer: C

If the motor is running while the PLC output LED is off, and the starter coil has been confirmed energized from an external source, then something other than the PLC output is holding that coil in. A bypass switch, a hand-off-auto selector left in hand, or a parallel wire can energize the starter directly. This is a safety concern: if the PLC output is supposed to be the only control of that motor, the alternate path has to be found, documented, and either removed or interlocked. Trace the starter coil wiring back to its source. The confirmed external source is what rules out the two module faults offered here - a shorted output device or a dead status light would both put the source back inside the module.

Q36. Answer: D

Real power = $V \times I \times \text{PF} = 120 \times 15 \times 0.75 = 1,350\text{ W}$. Apparent power is what the conductors actually carry: $V \times I = 1,800\text{ VA}$, and quoting that figure in watts is the most common error here. Dividing by the power factor instead of multiplying gives 2,400 W, a number larger than the apparent power, which is impossible. Using $\sin \theta$ in place of $\cos \theta$ returns about 1,190, but that is the reactive power in VAR, not the real power in watts. Only the real power does useful work; the reactive component is stored and returned each cycle by the circuit inductance.

Q37. Answer: D

Safety relays/PLCs (designed and rated to IEC 62061 or ISO 13849-1) monitor safety functions such as E-stops, light curtains, and guard interlocks using redundant, self-diagnostic circuits. On fault detection, they cut power to hazardous functions so the machine reaches a safe state before harm occurs. **In Canada those standards reach the shop floor through CSA Z432, Safeguarding of Machinery**, which requires safety-related parts of control systems on newly manufactured machinery to provide functional safety performance as determined by ISO 13849-1 or IEC 62061.

Q38. Answer: C

TEFC (Totally Enclosed Fan Cooled) motors are sealed against contaminants and have an external cooling fan — suitable for dusty, wet, or contaminated environments. ODP (Open Drip-Proof) motors are ventilated (cooling air passes through) — suitable for clean, indoor, protected locations only.

Q39. Answer: A

Equipotential bonding mats ensure that the floor, equipment, and person are at the same electrical potential, preventing dangerous current flow through the worker during a ground fault. They are commonly used on metal grating and in substations, where step and touch potential hazards are greatest.

Q40. Answer: B

The motor nameplate provides rated electrical, mechanical, and thermal data: voltage, phase, frequency, FLA, HP/kW, RPM, duty cycle, insulation class, service factor, efficiency, enclosure type, and NEMA/IEC frame designation - all critical for proper motor selection, installation, and protection. The nameplate FLA is the figure the overload device is selected from; it is not the figure the overload device is set to.

Q41. Answer: D

The wrong thermocouple type in the controller produces a systematic error that grows with temperature. Type J (iron/constantan) puts out more millivolts per degree than Type K (nickel-chromium/nickel-alumel). At 230°C a Type J junction produces roughly 12.4 mV, but a controller looking that value up in a Type K table — where about 12.4 mV corresponds to a little over 300°C — reports a much higher temperature. Because the two curves diverge as temperature climbs, the error grows with the process, which is exactly what the technician sees. The other explanations do not fit the evidence: a cold-junction or terminal-block problem shifts the reading by a roughly constant amount and does not scale with process temperature, an open extension wire drives the input to an upscale or downscale burnout alarm rather than a plausible number, and reversed polarity makes the reading move the wrong way as the furnace heats, not read high.

Q42. Answer: B

A 2-wire (loop-powered) transmitter draws its operating power from the 4–20 mA loop current. A 4-wire transmitter has a separate power supply (120V AC or 24V DC) and outputs a 4–20 mA signal independently.

Q43. Answer: B

With the secondary open, the primary current acts solely as magnetizing current, fully magnetizing the CT core. The core saturates and the collapsing magnetic flux induces extremely high, potentially lethal voltage spikes (thousands of volts) on the open secondary terminals.

Q44. Answer: D

CEC Rule 8-102 requires that voltage drop not exceed 3% in a feeder or branch circuit, and not exceed 5% overall from the supply side of the consumer's service to the point of utilization. This is mandatory 'shall not exceed' language, not a design suggestion, and an inspector can write it up. At 6.7% the branch circuit is over the limit, so the conductor is undersized for a 50 m run at 20 A. Voltage drop is current times resistance, and the only listed action that reduces the resistance of the run is a larger conductor: more cross-sectional area means less resistance per metre and less drop. A regulator at the load end hides the symptom while leaving the same heating in the conductor, and changing the load does not correct an installation that fails the rule.

Q45. Answer: D

Impedance $Z = \sqrt{R^2 + (X_L - X_C)^2}$. It is the complete opposition to AC current — the vector sum of resistance (R), inductive reactance (X_L), and capacitive reactance (X_C) at a specific frequency.

Q46. Answer: B

Y-Δ starting connects windings in star (Y) first, applying $1/\sqrt{3}$ of line voltage per winding, reducing starting current and torque to 1/3 of DOL values. After acceleration, the starter switches to delta (Δ) for full power.

Q47. Answer: D

PTC thermistors or bimetallic thermostats embedded in motor windings directly measure winding temperature. When temperature exceeds the setpoint, they trip or signal the motor control circuit to stop the motor before insulation damage occurs.

Q48. Answer: A

4mA is the minimum live-zero standard — 3.6mA indicates a transmitter fault. In a 4-20mA system, 4mA = 0% process. Under NAMUR NE 43, which many transmitters follow, 3.8 to 20.5mA carries measurement information, while 3.6mA or less (or 21mA or more) is the transmitter's failure signal. A broken signal wire opens the loop and drops the current to about 0mA, not 3.6mA. Check supply voltage first (the voltage at the transmitter terminals must meet the manufacturer's minimum after line and load drops), then check zero trim and recalibrate or replace the transmitter.

Q49. Answer: A

Ohm's Law: $V = I \times R$. Voltage (volts) = Current (amperes) × Resistance (ohms). Derivations: $I = V/R$, $R = V/I$. Applies to DC and resistive AC circuits.

Q50. Answer: A

An E-stop must be a hardwired circuit built on normally-closed, direct-opening contacts, because a stop that exists only in software fails with the processor or the program that hosts it. The contacts are wired in series in the control circuit so that a broken conductor or a loose terminal drops the circuit out and stops the machine, whereas a normally open contact would leave the same fault silently disabling the stop. Machine stopping functions are classified as stop category 0, an immediate removal of power, or stop category 1, a controlled stop followed by removal of power. A hardwired E-stop interrupts the motor control circuit and removes hazardous energy independently of what the PLC program is doing.

This mock was 50 of the 130 questions

The **442A Industrial Electrician Complete Question Bank** prints all 130, laid out like this mock: questions first, answers kept apart, so you can test yourself on paper. You get two PDFs:

Complete Question Bank · 80-page printable PDF

- **Part 1:** all 130 questions with the answers hidden, grouped by topic
- **Answer sheet:** circle your answers on it, so the question pages stay clean for another attempt
- **Part 2:** a quick answer key to mark your paper in one pass
- **Score by Topic** grid: shows which topic to study next
- **Part 3:** the correct answer, a written explanation and the key concept for every question
- **Part 4:** a full-length 100-question practice exam made from those same questions, mixed across topics, with a timing box, an answer sheet and a key

Exam Revision Notes · 19-page PDF, included

- The key concept behind every question, grouped by topic and tagged with its question number in the bank
- **Numbers & Specs** quick reference: the figures and units in one section

CA\$24 · one-time purchase · instant download from Ko-fi · printable on US Letter

Get the 442A bank — CA\$24 →

Working from a printed copy? Type redsealquiz.ca/go/442a-bank.html

Prefer to keep practising online? All 130 questions are free at redsealquiz.ca/442a.html. The bank is the printable edition, with the answer sheet, key, score grid and revision notes.

Price in Canadian dollars as of October 2026; Ko-fi shows the current price before you pay. Corrections to the bank go into the same file at no extra cost.

© 2026 · redsealquiz.ca/442a.html · For personal study use only. Independent, unofficial study resource — not affiliated with or endorsed by the CCDA, the Red Seal Program, or any apprenticeship authority. See "About This Material".