



pocket.watch

© (or "Copyright") (2018) RTR Production, LLC, RFR Entertainment, Inc. and Remka, Inc., and Pocket.Watch, Inc., dba pocket.watch.
All Rights Reserved.

RYAN'S WORLD 4-WHEEL RIDE-ON TOY

STOP!

DO NOT RETURN TO STORE.

**This product cannot be returned for a refund
after it has been unpacked and used.**

**Call us Toll-Free
at 1-866-424-0500
or Fax us at 1-775-248-5155
for assistance and information
from our trained technical staff.**

CAUTION: THIS IS AN ELECTRONICALLY OPERATED PRODUCT.

The charger is an electronically operated product – not a part of the toy.

Not recommended for children under 3 years of age.

As with all electronic products, precautions should be observed
during handling and use to prevent electric shock.

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local



Table of Contents

Important Information	2
Charging and Installation	4
Rules for Riding Safety.....	5
Parts	6-7
Assembly Instructions	8-10
Battery Instructions	11
Operation Instruction	12
Vehicle Care	13
Problem & Solution	14
Limited Warranty	15
Product Registration	16

Notes:

Important Information

- **ADULT ASSEMBLY REQUIRED!**

- The battery must be charged for 18 hours before the toy's first use. To start charging the battery before starting assembly, see Battery Charging and Installation information. See Battery Charging instructions on page 5 of this manual.
 - Instruct children on safe operation and driving rules before they take their first ride:
 - *Do not allow more than one rider at a time*
 - *Sit in the proper position on the toy when riding*
 - *Always wear shoes when riding the toy*
 - *Do not allow other children near the toy when riding*
 - *Do not place your hands, feet, or any part of your body, clothing, or other articles near moving parts while the toy is in operation.*
 - Instruct children to bring the toy to a complete stop before switching between forward and reverse.
 - Do not overload the vehicle or exceed the maximum weight capacity of 55lbs. (25 kg)
 - For all questions, please contact us at **1-866-424-0500**.
 - **Please read this manual completely** for operation and safety information before using the toy. Keep these instructions for future reference.

**For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local**





RYAN'S WORLD

4-WHEEL RIDE-ON TOY

Parent and Rider Manual

**With directions
for assembly and operation.**

Please read this manual before assembly.
Remember to save your receipt.

6-volt Rechargeable Battery Powered Ride-on Vehicle

3-5
Years Old



WARNING:
Adult assembly required.

WARNING:

CHOKING HAZARD - Small parts.
Not for children under 3 years.

MAX WEIGHT: 55 LBS. (25 KG)

MAX RIDERS: 1

MAX SPEED: 2.5MPH (4 KPH) FORWARD

EASY PUSH-BUTTON OPERATION

**6 VOLT BATTERY AND CHARGER INCLUDED.
WORKS ON HARD SURFACES AND GRASS.
CONTAINS LEAD ACID BATTERY**

RECHARGEABLE BATTERY INCLUDED

CONTAINS SEALED LEAD-ACID BATTERY. MUST BE RECYCLED OR DISPOSED OF SAFELY.

**FOR FURTHER INFORMATION REGARDING THE BATTERY AND THE DISPOSAL OF THE BATTERY,
PLEASE CALL: 1-866-424-0500**

REQUIRES ONE 6 VOLT LEAD ACID BATTERY (INCLUDED)

KEEP ENCLOSED OPERATORS MANUAL FOR IMPORTANT SAFETY INFORMATION.

WARNING:

**RISK OF FIRE. DO NOT BYPASS FUSE. REPLACE ONLY WITH SAME TYPE 15A FUSE BATTERY PACK.
TO REDUCE RISK OF INJURY, ADULT SUPERVISION IS REQUIRED. NEVER USE IN ROADWAYS OR NEAR MOTOR VEHICLES.**

**NEVER USE ON OR NEAR STEEP INCLINES OR STEPS.
NEVER USE NEAR SWIMMING POOLS OR OTHER BODIES OF WATER. ALWAYS WEAR SHOES.**

MAX WEIGHT OF 55 LBS. (25 KG)

**CAUTION: SCREWS CONTAIN SHARP POINTS
AND EDGES. ADULT ASSEMBLY REQUIRED.**

For assistance with your assembly call:

1.866.424.0500 toll-free
417.206.0563 Local

**⚠ CAUTION: The battery and charger are not toys.
All battery charging must be done by an adult.**

The battery is located under the seat. Use the provided screwdriver to remove the seat

- The battery must be charged 18 hours before it's first use. The battery must be in the upright position before charging, and be very careful to avoid any contact to both terminals at the same time.
- To disconnect the battery, squeeze the tabs of the connector and pull. Hold the connectors firmly, and do not pull the wires.
- Connect the battery charging line with the charger connector, then plug the charger into the wall outlet.
- Make sure to only plug the charger into standard 120V wall outlets. Use only the charger supplied. The charger has the rating: Input AC 120V 60Hz, Output DC7.0V 0.8A.
- You must recharge the battery for 8-12 hours after each time you use the toy. Never charge for more than 16 hours.
- Disconnect the charger from the wall outlet and then the charger from the battery. If you are not going to use the toy for a long period of time, make sure you recharge the battery at least once a month.
- Never lift or carry the battery by the wires or connector, this can cause damage. Lift and carry the battery by the case only.
- Do not charge or store the battery upside down. Charging the battery produces explosive gasses. Make sure to charge the battery away from flames, sparks, and lit cigarettes. Always charge in a well ventilating area.

CARE:

- Always charge the battery before storing the vehicle for a long period of time. Make sure to charge the battery at least once a month, even if the toy is not being used.
- Never let the battery run down completely before charging.
- Never leave the battery in a discharged condition. It may cause permanent damage.
- Never store the battery in temperatures above 75 °F (28.8 °C) or below 10 °F (12.2 °C)
- Before each charge examine the battery, charger, and their connectors for excessive wear or damage. If you find damage, do not use the battery or charger until you have replaced the worn or damaged part.
- Make sure to return exhausted batteries to an approved lead-acid battery recycler or contact your local authority accordingly.

DISPOSAL:

- Your vehicle's battery is a sealed lead-acid battery. You must recycle or dispose of it in an environmentally sound manner.
- Never dispose your battery in the regular, household trash. The incineration, land-filling, or mixing of a sealed lead-acid battery with your household trash is prohibited by law in most areas.
- Make sure to return exhausted batteries to an approved lead-acid battery recycler or contact your local authority.
- Always remove exhausted batteries from your toy. Dispose of dead batteries properly; never burn or bury them.
- Contact Customer Service at 1-866-424-0500 to purchase a replacement battery. You will receive free shipping with the purchase of a battery.
- To locate a service center, contact your local waste management company.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Safety

Rules for Riding Safety

⚠ WARNING: Adult Supervision Required

- Always Teach Safety First.
- While most children can develop the physical skills necessary to operate this toy, it is important to remember that they do not yet have mature judgment skills. Children should never be allowed to ride this toy without adult supervision. Before any child rides this toy, an adult must evaluate the child's skill levels and abilities to operate the toy safely. Even after instruction, hazards are not always anticipated or recognized by children. Before any child operates the toy, teach them appropriate safety rules.
- THERE IS NO SUBSTITUTE FOR DIRECT ADULT SUPERVISION.

⚠ WARNING: Safety Riding Rules

To reduce the risk of injury, adult supervision is required.

- Always sit only on the seat in the toy.
- Always wear shoes.
- No more than one rider at a time.
- Do not operate on loose dirt, sand or gravel.
- Do not operate near drop-offs, obstructions, swimming pools or other bodies of water.
- Do not operate on roadways on the street or near moving vehicles.
- Do not operate on or near steep inclines or steps. Use on generally level ground only.
- Do not operate in the dark as unexpected obstacles could cause a crash.
- Do not operate on slopes. The toy may accelerate or roll backwards at unsafe speeds even if the pedal is released.
- Do not place anything near moving parts such as motors, gears or wheels. Rotating parts can snag hair, fingers, etc. causing serious injury.
- Do not operate near flammable vapors (such as gasoline, paint thinner, acetone, liquid wax, etc.).
- Electrical components can produce an internal spark when first turned on or off. Using the toy near flammable liquids or vapors could cause an explosion or fire resulting in serious injury or death.


Specifications

Suitable Age:	3-5 years
Battery:	6V 5AH x 1
Charge Time:	8-10 hours
Charge:	Input: depends on local voltage output – DC 7v 800mA
Load Capacity:	Under 55 lbs. (25 kg)
Car Size:	44.5" x 25.4" x 17.8" (1130 mm x 646 mm x 452 mm)
Speed:	2.5 MPH (4 KPH)

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Parts

Parts Diagram



No.	Description	Stock No.
1	Vehicle body	
2	Front wing	
3	wheel	
4	wheel cover cap	
5	seat	
6	Top air intake	
7	Rear wing	
8	Steering wheel	
9	Windshield	
10	Gear shifter	
11	(R) Rearview mirror	
12	(L) Rearview mirror	
13	Left axle	
14	Right axle	
15	Gearbox	
16	Rear wheel axle	
17	Battery pack	
18	Battery handle	
19	Manual	
20		
21		
22		
23		
24		
25		
26		

**ACTION
WHEELS**

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local


Parts

Pre-assembly Part and Tool Identification


All items on this page are included in this package.




Rear Axle - 1




Rear Wing - 1



Top Air Intake - 1




Steering wheel - 1




wheels - 4



wheel cover cap - 4



Phillips Screwdriver - 1




Socket wrench - 1

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

ACTION
WHEELS


Assembly Instructions



Install Front Wheels (Right and Left)

Remove the nut from the front axle using the wrench provided. Pull off the small washer. Place the front wheel on the axle. Replace the small washer and nut on the wheel and then tighten. Add the wheel cover cap over the nut as shown in Diagram 1.


Repeat steps on opposite side.



Install Rear Wheels (Right and Left)

Remove the nut and washer from left and right sides of the rear axle with the wrench provided. Slide the end through the opening in the body and across through the hole in the gear box as shown in Diagram 2.

To install Rear Right wheel, slide the wheel onto the axle. Replace the Washer and Nut onto axle and tighten Nut securely with the wrench provided. Align the Wheel Cover Cap with Wheel Cover and apply pressure until snapped into place. Please Refer to Diagram 3.




To install Rear Left wheel, slide the Wheel Connector onto the axle first to make the indicated side outward as shown. Then slide the Wheel onto the axle and align Wheel with Gear Box. Replace the Washer and Nut onto axle and tighten Nut securely with the wrench provided. Align the Wheel Cover Cap with Wheel Cover and apply pressure until snapped into place. Please Refer to Diagram 3.

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Assembly Instructions


4



Install Sound Batteries in Steering Wheel

Remove battery cover by loosening screw with screwdriver provided. Place inside battery box (3x 1.5V AA Batteries Not Supplied). Confirm that batteries are positioned with their polarities correct as marked. Replace cover and tighten with the screw with screwdriver.


5



Install Steering Wheel

Remove the Steering Wheel Assembly and place onto the steering column. Align the bolt holes so the steering wheel is correctly positioned on the steering column then tighten the nut and bolt provided. See Diagram 5.


6



Install Battery Connector

Identify the battery connector and power cable. Align them correctly so the positive and negative connections are lined up and press the connectors together. Do not force the connection, if they don't go together smoothly check your alignment assuring that positive is connecting to positive and negative to negative. See Diagram 6.

7




Install Seat

Remove the seat assembly from the packaging. Install the seat as shown in Diagram 7, aligning the tabs and slots. Confirm that the seat is firmly in the correct position and turn the seat lock to close which will secure the seat in place. Turn the seat lock to open to remove the seat.

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Assembly Instructions


8



Install Top Air Intake

Make sure the hooks on the top air scoop align with slots on the body and snap into place, you will hear a solid click when the top air scoop is correctly fitted.

9




Install Rear Wing

Make sure the hooks on the rear wing plate align with slots on the body and snap into place ,you will hear a solid click when the rear wing plate is correctly fitted.


For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Battery Instructions



Recharging the Battery

Remove the seat by turning the locking knob to open and lifting the seat up from the car. Disconnect the battery connector from the power cable and then connect the battery connector to the charger connector. The red light will show while battery is charging. After charging battery for no more than 12 hours reconnect the battery connector to the power connector and reinstall seat as shown in Diagram 7.




Change fuse

To change the fuse disconnect the battery as shown in Diagram 10. Remove fuse cover and remove bad or damaged fuse. Replace with the identical fuse provided on top of the battery. Replace the fuse cover as shown in Diagram 11.

***Never bypass the fuse or use any other value than the supplied replacement.**

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local


Operation Instructions



Steering Function


Realistic steering with conveniently placed buttons for "HORN" and "Engine start up" and sound playback.

Note: Make sure batteries are installed correctly behind the steering wheel before use.



Operation Controls

Make sure driver is correctly sitting in the seat. Press the power switch. Adjust the shifter into the forward or reverse position and press the pedal with foot to move vehicle.



For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Maintenance

Toy Care

Check all screws, cap nuts and protective coverings regularly and tighten as required. Check plastic parts on a regular basis for cracks or broken pieces.



This product should be checked by adult before use and be used only under constant adult supervision.

During snow or rainy weather, the vehicle should be stored inside or under a protective cover. Remember to charge the battery at least once per month while your vehicle is not in regular use.



Avoid operating the vehicle in wet or snowy conditions and do not spray the vehicle with a hose. Do not wash the vehicle with soap and water. Water or moisture in the motors or electrical switches can cause them to corrode and could cause switch or motor failure.



Avoid operating the vehicle on sand, loose dirt or gravel. Sand, loose dirt or gravel in the motors or electrical switches can cause them to jam and could cause switch or motor failure.



The vehicle can be wiped down with a soft, dry cloth. For a shiny finish, you can wipe plastic parts with a non-wax furniture polish applied to a soft-cloth. Do not use automotive wax. Do not use soap and water or spray the vehicle with a hose.



The car should have its power switched to off when not in use and it is advised that the battery should be disconnected if the unit will not be used for a long period of time.



For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Problem & Solution

PROBLEM	ANALYZE	SOLUTION
Car doesn't work	• Low power	Recharge the battery
	• Blown Fuse	Replace the blown fuse with the same type and value fuse
	• Lost wheel nut	Replace the nut with the correct size and tighten
	• Loose battery connection	Re-fit and tighten the connector, or if damaged replace the connector
	• Exhaust & bad battery	Replace with a new battery from BallardPacific
	• Damaged electric parts	Contact BallardPacific Service at BallardPacific.com or call 1-866-424-0500
	• Damaged motor	Contact BallardPacific Service at BallardPacific.com or call 1-866-424-0500
Battery can't be recharged	• Loose battery connection	Re-fit and tighten the connector, or if damaged replace the connector
	• No power to charger	Check if charger is plugged in and is properly connected to the battery connector
	• Loose battery connection	Replace the charger with a new unit from BallardPacific
Short of run time	• Battery charge is low	Recharge the battery fully
	• Battery is old	Purchase a new battery from Ballard Pacific
Noise & Heat during recharge	• Some heat and noise is normal	No action needed
Low Speed	• Old battery	Use new battery
	• Low power	Recharge the battery fully
	• Over burdened	Do not exceed max weight of 55lbs or (25Kg)
	• Not used on flat surfaces	The car is designed for relatively flat surfaces
Gear box is noisy	• Gear box is damaged	Contact BallardPacific Service at BallardPacific.com or call 1-866-424-0500
	• Motor is damaged	Contact BallardPacific Service at BallardPacific.com or call 1-866-424-0500
Car vibrates or shakes	• Problem with motor wire connection	Carefully check connections and tighten as needed
	• Problem with motor	Contact BallardPacific Service at BallardPacific.com or call 1-866-424-0500
No sound or light when running	• Loose sound & light wire	Carefully check connections and tighten as needed
	• Light control is damaged	Contact BallardPacific Service at BallardPacific.com or call 1-866-424-0500
Car wont stop while running	• Electrical malfunction	Contact BallardPacific Service at BallardPacific.com or call 1-866-424-0500

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Assembly Instructions

**DON' T RETURN YOUR
VEHICLE TO THE STORE.**

Do not take back to store, call customer service with any problems or questions.

Ballard Pacific Resources, Inc. offers the following limitations, terms and conditions to the original owner of the Ballard Pacific Resources, Inc. electric Ride-On Toy. Should this Ballard Pacific Resources, Inc. electric Ride-On toy or an part be determined defective by Ballard Pacific Resources, Inc. to be covered by this limited Warranty, it will be repaired or replaced, at Ballard Pacific Resources, Inc. sole option, which will be conclusive and binding. Under no circumstances does this limited warranty include the cost of travel or shipment to and from any retailer or consumer. Such cost, if any, shall be borne by the original or subsequent owner.

This Ballard Pacific Resources, Inc. electric ride-on toy has not been designed or engineered for ramp riding, jumping, aggressive riding, in severe climates or over severe terrain, riding with heavy loads (over 55 lbs or 25 kg) or any similar activities. Such uses may damage the Ballard Pacific Resources Inc. electric ride-on toy, that can cause serious injury to the rider and in all cases will void this warranty.

6 Months from the date of the purchase on vehicle

Ballard Pacific Resources, Inc. Electric Ride-On display, throttle and throttle assembly, control wiring harness, wiring and wiring harness, motor and associated transmission and all components not directly associated with the 6V battery are warranted from 6 months from date of purchase to The ORIGINAL PURCHASER against any defects in material, manufacturing, and/or workmanship. If there is any evidence of consumer repair the warranty is voided. Any claim of damage under this clause cannot be due to owner abuse or neglect and must first be reported to Ballard Pacific Resources, Inc. Customer Service and a Return Merchandise Authorization (RMA) tag to be issued.

3 Months from the date of the purchase on battery

The battery must be charged for a full 18 hours before the units first use. The 6V battery and battery charger (AC Adaptor) that is included with the original vehicle is warranted to be free from defects in material, parts and/or workmanship, again not due to owner abuse or neglect. If there is evidence of customer repair or use other's battery or charger the warranty is voided. This limited warranty is only valid to the original purchaser and must first be reported to Ballard Pacific Resources, Inc. Customer Service and a Return Merchandise Authorization (RMA) tag be issued.

Wheels are considered a wear and tear item and are only under warranty in the event of manufacturer defect.

Items not covered under warranty terms under any conditions

- 1.Damage due to failure to maintain the battery as accurately described on various product warning stickers and the products owner's manual.
- 2.Damage due to maintenance or the actual damage caused by the lack of maintenance.
- 3.Damage due to improperly assembled products.
- 4.Damage due to climatic or environmental damage, various cleaners and/or chemicals that may result in a damages finish.

This warranty does not cover and is intended to exclude, any liability on the part of Ballard Pacific Resources, Inc. Whether under this warranty or implied by law or indirect or consequential damages for breach of warranty.

This warranty gives you specific legal rights. You may also have other rights that vary from state to state and province to province. In those states that do not allow the exclusion of implied warranties or limitation of incidental or consequential damages, the above limitations or exclusions may not apply to you. This warranty applies to the United States, Canada.

DON' T RETURN YOUR VEHICLE TO THE STORE. Should you require service or assistance with your vehicle during the warranty period, contact our trained technical staff at Ballard Pacific Resources, Inc. 1-866-424-0500.

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

Product Registration

Note:

Activation of your warranty gives you FREE telephone and online technical service help. Please fill out registration below and immediately mail with your sales receipt to:

Ballard Pacific Resources, Inc.
410 S. Adele Avenue
Joplin, MO 64801



pocket.watch

© (or "Copyright") (2018) RTR Production, LLC, RFR Entertainment, Inc. and Remka, Inc., and Pocket.Watch, Inc., dba pocket.watch. All Rights Reserved.

Designed, manufactured and distributed by
Ballard Pacific Resources.
All rights reserved.

For a record of your purchase, fill out immediately
and send to: **Ballard Pacific Resources, Inc.**
410 S. Adele Ave., Joplin, MO 64801

Ballard Pacific
Resources, Inc.

Owner's Name: _____ (Please Print)

Address: _____ (Please Print)

City: _____ State: _____ Zip: _____

Phone: _____ Email: _____

Date Purchased: _____ Place of Purchase: _____

Model Name: _____ Serial Number: _____

For assistance with your assembly call:
1.866.424.0500 toll-free
417.206.0563 Local

