

BRAKES

Operate the front and rear brakes to ensure these are working well. Oil all linkages and check that brake fluid is sufficient. Free-play for front brake lever and rear brake pedal should be 15-20mm.

INSPECTING FRONT BRAKE LEVER.



INSPECTING REAR BRAKE PEDAL



How to check Brake Fluid:

- 1. Place your motorcycle in an upright position
- 2. Check that the brake fluid reservoir is horizontal and that the fluid level is:
 - ✓ Above the LOWER level mark for the Front brake fluid reservoir.
 - ✓ Between the LOWER and UPPER level marks for the Rear brake fluid reservoir.

