ALPINE RESEARCH | INERT TRAINING SUPPRESSOR (TRAINER)

Installation & Use – Force-on-Force Training with UTM / Simunition Marking Ammunition

WARNING: Mishandling firearms can cause serious injury or death. Only properly trained officers should handle weapons, install, or remove suppressors and training cans.

WHAT THE TRAINER IS

The Alpine Research trainer is an inert, blue-finished alloy steel replica of a real suppressor, matching its length, weight, and mount. The blue finish marks it as non-functional. Installed on a UTM or Simunition conversion, it lets officers train with their own duty rifles using less-than-lethal training ammunition.

FOUR CARDINAL RULES OF GUN SAFETY

1. **Treat every firearm as if it is loaded.**
2. **Never point the muzzle at anything you are not willing to destroy.**
3. **Keep your finger off the trigger until your sights are on target and you have decided to shoot.**
4. **Be sure of your target and what is beyond it.**

SWAPPING YOUR SUPPRESSOR FOR THE TRAINER (in order)

1. **Wait until the rifle and suppressor are cool to the touch.** Do not touch a hot suppressor or attempt to remove it.
2. **Point the muzzle in a safe direction**
3. **Remove the magazine** from the rifle.
4. **Lock the bolt to the rear and visually inspect the chamber.** Verify the chamber is empty and the rifle is safe.
5. **Remove the Alley Cat 556 suppressor** by twisting it clockwise*. Place it in a safe location.
6. **Install the Alpine Research trainer** by screwing it counterclockwise* onto the Spooky One flash hider until it stops. Only gentle force is necessary.

RETURNING THE RIFLE TO DUTY (in order)

1. **Point the muzzle in a safe direction.**
2. **Remove the magazine.**
3. **Lock the less-lethal (Simunition / UTM) bolt to the rear.**
4. **Verify the chamber is empty** and the rifle is safe.
5. **Remove the training suppressor** by twisting it clockwise* until the threads are disengaged.
6. **Depress the takedown pin on the lower receiver** and remove the Simunition / UTM bolt carrier group.
7. **Allow the upper and lower receiver groups to hinge on the pivot pin.**
8. **Remove your Simunition or UTM force on force bolt carrier group.**
9. **Before installing the live bolt carrier group, visually inspect the bore.** Look down the barrel from the back of the upper receiver and verify no less-lethal projectiles are present obstructing the bore. If a less-than-lethal round is lodged in your barrel, immediately notify your department armorer and down the rifle until the bore obstruction is cleared. Firing live ammunition into a blocked barrel bore could lead to serious injury or death.
10. **Re-install the Alpine Research BCG.**
11. **Close the takedown pin.**
12. **Re-install the Alley Cat 556 suppressor** by turning it counterclockwise* until fully seated. Use moderate to high force once the suppressor begins to contact the flash hider taper.

**Direction as viewed from the front of the rifle, looking at the suppressor endcap.*

DO NOT FIRE TRAINING AMMUNITION THROUGH A REAL SUPPRESSOR.
Plastic UTM and Simunition projectiles can become unstable in flight, strike a baffle, and come to rest inside your suppressor. If not detected this can lead to suppressor damage during the next live fire session, as well as serious injury or death. Always remove the real suppressor and install the trainer before firing training ammunition.

NO LIVE AMMUNITION IN THE TRAINING AREA. Never fire live ammunition with the trainer installed. Remove all live rounds and magazines from the training area before any training ammunition is introduced, and follow your agency's force-on-force safety protocols.