

Washing instructions

Pin this next to the board. Washing is on the other sheet.
Generic front loader, 1–8 kg · Generic steam iron

ON THE BOARD

#	Pile	Thermostat	Steam	How
1	Dark	••	yes	Inside out, medium heat
2	Merino Wool	••	yes	Only if you must
3	Cashmere Blend	••	yes	Low heat through a pressing cloth
4	White	•••	yes	Iron while slightly damp, steam on
5	Coloured	•••	yes	Steam, but turn prints and dark panels inside out first
6	Denim	•••	yes	Inside out on cotton heat if you want them crisp
7	White Socks	do not iron	—	Don't
8	White Towels	do not iron	—	Don't
9	Coloured Socks	do not iron	—	Don't
10	Coloured Towels	do not iron	—	Don't
11	Microfibre Towels	do not iron	—	Don't
12	Black Socks	do not iron	—	Don't
13	Raw Denim	do not iron	—	Don't
14	Synthetic Activewear	do not iron	—	Don't
15	Gym Socks	do not iron	—	Don't
16	Wool Trainers	do not iron	—	Don't




thermostat

The ring is the iron's thermostat as it sits on the dial, and the red pointer is where to turn it. The blue band is the zone where it makes steam; a setting below it is a dry iron. A crossed-out ring means leave the iron in the cupboard.

1. •• — wool, silk · 150 °C

3 piles



Thermostat on ••
inside the steam zone

HOW

Dark

Inside out, medium heat. Steam, don't press hard — shine on dark cotton doesn't come out.

Merino Wool

Only if you must: pressing cloth, no weight. Hanging it in a steamy bathroom drops the creases without touching it.

Cashmere Blend

Low heat through a pressing cloth. Better still, steam it on a hanger and let the creases drop out on their own.

2. ••• — cotton, linen · 200 °C

3 piles



Thermostat on •••
inside the steam zone

HOW

White

Iron while slightly damp, steam on. Cotton takes all the heat the iron has.

Coloured

Steam, but turn prints and dark panels inside out first.

Denim

Inside out on cotton heat if you want them crisp. Steam.

3. Do not iron

10 piles



Leave the iron off
nothing on this card ever goes near the board

HOW

White Socks

Don't.

White Towels

Don't. Ironing crushes the pile flat and the towel stops drying you.

Coloured Socks

Don't.

Coloured Towels

Don't. Ironing crushes the pile flat and the towel stops drying you.

Microfibre Towels

Don't. Polyester and polyamide start melting around 110 °C, well before the iron does anything useful.

Black Socks

Don't.

Raw Denim

Don't. Pressing sets creases in the wrong places and flattens the fades that took months to earn.

Synthetic Activewear

Don't. Elastane starts degrading around 110 °C, and the technical finish goes with it.

Gym Socks

Don't.

Wool Trainers

Don't.