

Washing instructions

Pin this next to the machine. Ironing is on the other sheet.
Generic front loader, 1–8 kg · Generic steam iron

LOADS — ONE LINE, ONE WASH

Bold pile names share one wash.

Cottons 60°	Whites (on its own)	~2:30
Cottons 40°	Coloured shirts (on its own)	~2:15
Cottons 30°	Dark jeans (on its own)	~2:00
Wool 30°	Merino jumper (on its own)	~0:40
Easy Care 30°	Synthetic activewear (on its own)	~1:10

AT A GLANCE

#	Pile	Programme	°C	Spin	Time	Buttons	Softener	Detergent
1	Whites	Cottons	60	1200	~2:30	Eco	no	Universal powder, full dose
2	Coloured shirts	Cottons	40	1200	~2:15	Eco	yes	Colour liquid detergent
3	Dark jeans	Cottons	30	800	~2:00	Extra Rinse	no	Liquid detergent for dark/black
4	Merino jumper	Wool	30	400	~0:40	—	no	Wool detergent, half dose
5	Synthetic activewear	Easy Care	30	800	~1:10	Extra Rinse	no	A small dose of mild pH-neutral liquid detergent

CAN THESE SHARE A LOAD?

	1	2	3	4	5
1. Whites		C	C	P	C
2. Coloured shirts	C		C	P	C
3. Dark jeans	C	C		P	C
4. Merino jumper	P	P	P		P
5. Synthetic activewear	C	C	C	P	

OK — same drum C — colours would run into each other P — different programme, temperature, spin or options



The dials are drawn as they sit on the machine: twelve o'clock is Off, and the red pointer is where to turn it. Chips show every value the display steps through, filled in on the one you want.

1. Whites

~2:30

NO SOFTENER Cottons 60 °C · 1200 rpm

WASH



Temp: cold, 20, 30, 40, **60**

Spin rpm: 0, 400, 800, **1200**, 1400

Buttons: **Eco**, Extra Rinse

Cottons
1 clockwise from Off

DETERGENT

Universal powder, full dose

WASH TOGETHER WITH

nothing else — wash alone

DRYING

Tumble dry normal, or line dry in the sun.

NOTES

Wash whites on their own.

2. Coloured shirts

~2:15

SOFTENER OK Cottons 40 °C · 1200 rpm

WASH



Temp: cold, 20, 30, **40**, 60

Spin rpm: 0, 400, 800, **1200**, 1400

Buttons: **Eco**, Extra Rinse

Cottons
1 clockwise from Off

DETERGENT

Colour liquid detergent

WASH TOGETHER WITH

nothing else — wash alone

DRYING

Line dry inside out, or tumble on low.

3. Dark jeans

~2:00

NO SOFTENER Cottons 30 °C · 800 rpm

WASH



Temp: cold, 20, **30**, 40, 60

Spin rpm: 0, 400, **800**, 1200, 1400

Buttons: Eco, **Extra Rinse**

Cottons
1 clockwise from Off

DETERGENT

Liquid detergent for dark/black

WASH TOGETHER WITH

nothing else — wash alone

DRYING

Hang by the waistband and air dry.

~0:40

WASH



WASH TOGETHER WITH

DRYING

NOTES

— *Manufacturer care guide*

~1:10

WASH



WASH TOGETHER WITH

DRYING

NOTES

Inside out. Never softer.