init CMDs

AT+RESET

<wait 1 sec>
AT+BAND=868000000

AT+NETWORKID=1<id>
AT+ADDRESS=<addr>
AT+PARAMETER=12,7,1,4

AT+CPIN=LoRaSecure1234

AT+CRFOP=1

PROF