Pointcloud_Program_Manual

- 1. Running the Program as a Service
 - a. Creating a Systemd Service
 - b. Enabling and Starting the Service
 - c. Service Commands
- 2. Running the Program Manually
- 3. Software Directory Structure
- 1. Running the Program as a Service
 - a. Creating a Systemd Service

To run the program as a service for the first time (already done), and to see the display on startup:

i. Create a new systemd service file:

sudo nano /etc/systemd/system/kiosk.service

ii. Add the following content to the file:

[Unit]

Description=Kiosk Service

After=network.target

[Service]

User=pi

Environment="DISPLAY=:0"

WorkingDirectory=/home/pi/3dview

ExecStart=/usr/bin/python3 /home/pi/3dview/your_script_name.py

Restart=always

RestartSec=5s

[Install]

WantedBy=multi-user.target

- iii. Save the file and exit the editor (Ctrl+X, Y, Enter).
- b. Enabling and Starting the Service

Reload the systemd daemon and enable the service:

sudo systemctl daemon-reload sudo systemctl enable kiosk.service

c. Service Commands

In case you cannot see the display on startup, run these commands in sequence:

sudo systemctl start kiosk.service sudo systemctl status kiosk.service

sudo systemctl stop kiosk.service sudo systemctl restart kiosk.service

2. Running the Program Manually

To run the program manually through terminal command

sudo systemctl stop kiosk.service cd 3dView sudo python kiosk.py

3. Software Directory Format