

Shared Symmetric Memory Systems Computer Architecture

J. Daniel García Sánchez (coordinator)

David Expósito Singh

Javier García Blas

ARCOS Group
Computer Science and Engineering Department
University Carlos III of Madrid



- 1 Introduction to multiprocessor architectures
- 2 Centralized shared memory architectures
- 3 Cache coherence alternatives
- 4 Snooping protocols
- 5 Performance in SMPs
- 6 Conclusion



Increasing importance of multiprocessors

- There is a decrease in silicon and energy efficiency as more ILP is exploited.
 - Cost of silicon and energy grows faster than performance.

- Increasing interest in high performance servers.
 - Cloud computing, software as a service, ...

- Data intensive applications growth.
 - Huge amounts of data on the Internet.
 - Big data analytics.



TLP: Thread level parallelism

- TLP implies the existence of multiple program counters.
 - Assumes MIMD.
 - Generalized use of TLP outside scientific computing is relatively recent.
 - New applications:
 - Embedded applications.
 - Desktop.
 - High-end servers.



Multiprocessors

- A multiprocessor is a computer consisting of highly coupled processors with:
 - Coordination and use typically controlled by a single operating system.
 - Memory sharing through a single shared memory space.

Software models:

- Parallel processing: Coupled set of cooperating threads.
- Request processing: Independent process execution originated by users.
- Multiprogramming: Independent execution of multiple applications.



Most common approach:

- From 2 to tenths of processors.
- Shared memory.
 - Implies shared memory.
 - Does not necessarily imply a single physical memory.

Alternatives:

- CMP (Chip Multi Processors) or multi-core.
- Multiple chips.
 - Each one may (or may not) be *multi-core*.
- Multicomputer: Weakly coupled processors not sharing memory.
 - Used in large scale scientific computing.



■ Maximizing exploitation of multiprocessors:

With n processors, at least n processes or threads are needed.

Threads identification:

- Explicitly identified by programmer.
- Created by operating system from requests.
- Loop iterations generated by parallel compiler (e.g. OpenMP).

High-level identification performed by programmer or system software with threads having **enough** number of instructions to execute.



Multiprocessors and shared memory

SMP: Symmetric Multi-Processor


- Centralized shared memory.
- Share a single centralized memory where all have equal access time.
- All multi-cores are SMP.
- UMA: Uniform Memory Access
 - Memory latency is uniform.

DSM: Distributed Shared Memory

- Memory is distributed across processors.
- Needed when the number of processors is high.
- NUMA: Non Uniform Memory Access.
 - Memory latency depends on data location.
- Communication through access to global variables.




SMP: Symmetric Multi Processor





DSM: Distributed Shared Memory





- 1 Introduction to multiprocessor architectures
- 2 Centralized shared memory architectures
- 3 Cache coherence alternatives
- 4 Snooping protocols
- 5 Performance in SMPs
- 6 Conclusion



SMP and memory hierarchy

- Why using centralized memory?
 - Multi-level large caches decrease memory bandwidth demand on main memory accesses.

■ Evolution:

- 1. Single-core with memory in shared bus.
- 2. Memory connection in **separated bus** only for memory.



Cache memory

- Kinds of data in cache memory:
 - Private data: Data used by a single processor.
 - Shared data: Data used by multiple processors.

- Problem with shared data:
 - Datum may be replicated in multiple caches.
 - Contention is decreased.
 - Each processors accesses its local copy.
 - If two processors modify their copies . . .
 - Cache coherence?



Cache coherence

Thread 1

Iw \$t0 , dirx
addi \$t0 , \$t0 , 1
sw \$t0 , dirx

Thread 2

Iw \$t0, dirx

- \$t0 initially 1.
- Assuming write through.

Process	Instruction	P1 Cache	P2 Cache	Main memory
T1	Initially	Not present	Not present	1
T1	lw \$t0, dirx	1	Not present	1
T1	addi \$t0, \$t0, 1	1	Not present	1
T2	lw \$t0, dirx	1	1	1
T1	sw \$t0, dirx	2	1	1



Cache incoherence

- Why does incoherence happen?
 - State duality:
 - Global state → Main memory.
 - Local state → Private cache.
- A memory system is coherent if any read from a location returns the most recent value that has been written to that location.
- Two aspects:
 - Coherence: Which value does a read return?
 - Consistency: When does a read get the written value?



Conditions for coherence

Program order preservation

A read from processor P on location X after a write from processor P on location X, without intermediate writes on X by any other processor Q, always returns the value written by P.

Coherent view of memory:

A read from processor P on a memory location X, after a write form other processor Q on location X, returns the written value if both operations are separate enough in time and there are no intermediate writes on X.

Writes serialization:

Two writes on the same memory location by two different processors are seen in the same order by all the processors.



Memory consistency

- Defines in which point in time a process reading values will see a written value.
- Coherence y consistency are complementary:
 - Coherence: Behavior of reads and writes on a single memory location.
 - Consistency: Behavior of reads and writes with respect to accesses to other memory locations.
- There are different consistency memory models.
 - We will have a specific lecture on this problem



- 1 Introduction to multiprocessor architectures
- 2 Centralized shared memory architectures
- 3 Cache coherence alternatives
- 4 Snooping protocols
- 5 Performance in SMPs
- 6 Conclusion



Coherent multiprocessors

A coherent multiprocessor offers:

- Shared data migration.
 - A datum may be moved to a local cache and be used transparently.
 - Decreases remote data access latency and bandwidth demand to shared memory.
- Shared data replication simultaneously read.
 - Performs data copy in local cache.
 - Decreases access latency and read contention.

■ Critical properties for performance:

Solution: Hardware protocol for keeping cache coherence.



Kinds of cache coherence protocols

Directory based:

- Sharing state is kept in a directory.
- SMP: Centralized directory in memory or in LLC (Last-level cache).
- DSM: To avoid bottlenecks a distributed directory is used (more complex).

■ Snooping:

- Each cache keeps the sharing state of each block that it stores.
- Caches accessible through a broadcasting device (bus).
- All caches monitor broadcasting device to determine if they have a copy of the block.



- 1 Introduction to multiprocessor architectures
- 2 Centralized shared memory architectures
- 3 Cache coherence alternatives
- 4 Snooping protocols
- 5 Performance in SMPs
- 6 Conclusion



Coherence maintenance

■ Write invalidation:

- Guarantees that a processor has exclusive access to a block before performing a write.
- Invalidates the rest of copies that other processors might have.

- Write updates (write broadcasting):
 - Broadcasts all writes to all caches to modify block.
 - Makes use of more bandwidth

■ Most common strategy ⇒ Invalidation.



Memory bus use

Invalidation.

- Processor acquires bus and broadcasts the address to be invalidated.
- All processors are snooping the bus.
- Each processor checks if it has in cache the broadcasted address and invalidate it.
- There cannot be two simultaneous writes:
 - Exclusive use of bus serializes writes.

Cache misses:

- Write through:
 - Memory contains the last performed write.
- Write back:
 - If a processor has a modified copy, it sends it to a cache miss from the other processor.



Implementation

Invalidation:

Takes advantage from validity bit (V) associated to each block.

■ Writes:

- Need to know if there are other copies in cache.
 - If there are no other copies write broadcast is not needed.
- Sharing bit (S) is added to each associated block.
- When there is a write:
 - Bus invalidation is generated.
 - Transition from shared state to exclusive state.
 - No need to send new invalidations.
- When there is a miss cache in other processor:
 - Transition from exclusive state to shared state.



Basic protocol

- Based in state machine for each cache block:
 - State changes generated by:
 - Processor requests.
 - Bus requests.
 - Actions:
 - State transitions.
 - Actions on the bus.

- Simple approach with three states:
 - M: Block has been modified.
 - S: Block is shared.
 - I: Block has been invalidated.




Actions generated by processor

Request	State	Action	Description
Read hit	$S\toS$	Hit	Read data from local cache
Read hit	$M \to M$	Hit	Read data from local cache
Read miss	$I \rightarrow S$	Miss	Broadcast read miss on bus.
Read miss	$S\toS$	Replacement	Address conflict miss.
			Broadcast read miss on bus.
Read miss	$M \to S$	Replacement	Address conflict miss.
			Write block and broadcast read miss.
Write hit	$M \to M$	Hit	Write data in local cache.
Write hit	$S \to M$	Coherence	Bus invalidation.
Write miss	$I \rightarrow M$	Miss	Broadcast write miss on bus.
Write miss	$S \to M$	Replacement	Address conflict miss.
			Broadcast write miss on bus.
Write miss	$M \to M$	Replacement	Address conflict miss.
			Write block and broadcast write miss.



MSI Protocol: Processor actions






Actions generated by bus

Request	State	Action	Description
Read miss	$S \rightarrow S$	_	Shared memory serves miss.
Read miss	$M \rightarrow S$	Coherence	Attempt to share data. Place block on bus.
Invalidate	$S \rightarrow I$	Coherence	Attempt to write a shared block. Invalidate block.
Write miss	$S \rightarrow I$	Coherence	Attempt to write a shared block. Invalidate block.
Write miss	M o I	Coherence	Attempt to write a block that is exclusive elsewhere Write back cache block.



MSI Protocol: Bus actions





MSI protocol complexities

- Protocol assumes that operations are atomic.
 - Example: It is assumed that a miss can be detected, bus acquired, and response received in a single action without interruption.
- If operations are not atomic:
 - Possibility for a deadlock or data race.

Solution:

Processor sending invalidation keeps bus ownership until invalidation arrives to the rest of processors.



Extensions to MSI

■ MESI:

- Add exclusive state (E) signaling that a block lives in a single cache but is not modified.
- Writing of an E block does not generate invalidations.

MESIF:

- Adds forward state (F): Alternative to S signaling which node must answer each request.
- Used by Intel Core i7.

■ MOESI:

- Adds owned state (O) signaling that block in memory is not updated.
- Avoids memory writes.
- Used by AMD Opteron.



- 1 Introduction to multiprocessor architectures
- 2 Centralized shared memory architectures
- 3 Cache coherence alternatives
- 4 Snooping protocols
- 5 Performance in SMPs
- 6 Conclusion


Performance

Use of cache coherence policies has impact on miss rate.

- Coherence misses emerge:
 - True sharing misses:
 - A processor writes to a shared block and invalidates.
 - A different processor reads a shared block.
 - False sharing misses:
 - A processor writes a shared block and invalidates it.
 - A different processor reads a different word from the same block.

Performance in SMPs


Performance when increasing L3



Source: Computer Architecture: A Quantitative Approach. 6 Ed Hennessy and Patterson, Morgan Kaufmann, 2017.




Contributions to L3 misses



Source: Computer Architecture: A Quantitative Approach. 6 Ed Hennessy and Patterson, Morgan Kaufmann, 2017.




Increasing number of processors



Source: Computer Architecture: A Quantitative Approach. 6 Ed Hennessy and Patterson, Morgan Kaufmann, 2017.



Increasing block size



Source: Computer Architecture: A Quantitative Approach. 6 Ed Hennessy and Patterson. Morgan Kaufmann. 2017.



- 1 Introduction to multiprocessor architectures
- 2 Centralized shared memory architectures
- 3 Cache coherence alternatives
- 4 Snooping protocols
- 5 Performance in SMPs
- 6 Conclusion

Summary

-Conclusion

- Multiprocessor as computer with multiple highly coupled processors with coordination, use, and memory sharing.
- Multiprocessors classified into SMP (Symmetric multiprocessors) and DSM (Distributed Shared Memory).
- Two aspects to consider in memory hierarchy: coherence and consistency.
- Two alternatives in cache coherence: directory and snooping.
- Snooping protocols do not require a centralized element.
 - But they generate more bus traffic.

References

Conclusion

Computer Architecture. A Quantitative Approach 5th Ed.

Hennessy and Patterson.

Sections: 5.1, 5.2, 5.3.

- Recommended exercises:
 - **5.1**, 5.2, 5.3, 5.4, 5.5, 5.6.



Shared Symmetric Memory Systems Computer Architecture

J. Daniel García Sánchez (coordinator)

David Expósito Singh

Javier García Blas

ARCOS Group Computer Science and Engineering Department University Carlos III of Madrid