

15 CARDS 2200000, CONTAINMENT INPUT

These cards are used optionally in NEW and RESTART problems when containment function is desired. If these cards exist, the CONTEMPT4/MOD5/PCCS (CONTL.DLL) module or CONTAIN 2.0 (contain20.dll) module, is loaded dynamically. If this card is omitted, the containment function is deactivated and containment data should not be entered.

15.1 Card 22000000, Control Card

W1(A) contempt or contain.

If you choose contempt, contl.dll will be loaded and CONTEMPT4/MOD5 module is used. If you choose contain, contain20.dll will be loaded and CONTAIN 2.0 module is used.

W2(A) new or restart

Restart function was not provided yet. If you want to run after system steady calculation, use 'new' option in the start of initial transient calculation

15.2 Card 22000001 ~ 22000099, Volume Linkage Identification Card

W1(I) volume identification number of time-dependent volume for containment

W2(I) compartment number of containment

The number of card should be total number of connections between system and containment

15.3 CHANGED PART FOR CONTAINMENT CODE INPUT

These cards are used for "inputc" file data of CONTEMPT4/MOD5/PCCS code. In unified calculation, the file names have been fixed by follows and cannot be changed by user.

Function	File name
Input :	inputc
Output :	outputc
Plot:	plotflc
Screen:	screenc

15.3.1 Card 1000501, Tagami Boundary Condition Card

W1(A)	time unit
W2(R)	TPEAK
W3(I)~W5(I)	Single transaction table number
W5(A)	heat transfer coefficient unit
W6(A)	blowdown energy unit
W7(R)	Total blowdown energy

15.3.2 Card 1YY1100 , Boundary Condition Card

W1(I)	ISHL : Heat Transfer Control for Nominal Left Boundary = 53 : Tagami Model = 70 : Almenas Correlation
W2(I)	ISTL
W3(I)	ISHR : Heat Transfer Control for Nominal Right Boundary = 53 : Tagami Model = 70 : Almenas Correlation
W4(I)	ISTR