Geekclock Code and Hardware Walkthrough


Andreas Müller

Chaos Singularity 2007

- Elektronik
 - Stromkreis
 - Gesetz von Ohm
 - Knotenpunkt- und Maschenregel
 - Komponenten
 - Using Microcontrollers
 - What is an MCU?
 - ATMega8 features
 - Differences from coding on a PC
- Geekclock Hardware
 - Hardware Overview
 - Circuit diagram
- Geekclock Software
 - Software concept
 - Structure Overview
 - Code Walkthrough

- Elektronik
 - Stromkreis
 - Gesetz von Ohm
 - Knotenpunkt- und Maschenregel
 - Komponenten
- Using Microcontrollers
- Geekclock Hardware
- Geekclock Software

Stromkreis



- Strom fliesst nur im geschlossenen Kreis
- hier sind LED und Widerstand in Serie
 - gleicher Strom fliesst durch beide Elemente
 - Spannungen über den Elementen sind unterschiedlich
 - bei Parallelschaltung wäre es umgekehrt

Ohm'sches Gesetz

Proportionalität zwischen Widerstand R, Strom I durch R, und Spannung U über R:

$$U = R * I$$

Beispiel von der letzten Folie – benötigter Widerstand?


- Spannung über Widerstand (Batteriespannung LED bias): U = 4.5V 2V = 2.5V
- Strom: LED soll ca 10mA haben
- Widerstand:

$$R = \frac{U}{I} = \frac{2.5V}{10mA} = \frac{2.5V}{0.01A} = 250\Omega$$

Knotenpunkt- und Maschenregel


Kirchhoff'sche Gesetze:

- Knotenregel: Summe aller Ströme in einem Knoten ist Null (→ es gehen keine Elektronen verloren)
- Maschenregel: Summe aller Spannungen in einer Masche ist Null (→ es fällt über einer idealen Leitung keine Spannung ab)



Widerstand

- Symbol: R
- Schaltzeichen: ----
- Kenngrösse: Widerstand mit Einheit Ohm (Ω)
- Spannung über Widerstand ist proportional zu Strom
- Farbcodierung gibt Widerstandswert an



Kondensator

- Symbol: C
- Schaltzeichen:
- Kenngrösse: Kapazität mit Einheit Farad (F)
- Schaltzeichen für Elektrolytkondensatoren: 🖺
- speichert Strom / stabilisiert Spannung
- Werte sind meist direkt aufgedruckt



Diode und LED

- Symbol: D
- Schaltzeichen: bzw. (LED)
- Dioden lassen Strom nur in eine Richtung durch → Einbaurichtung (Polarität) beachten
- in der Geekclock als Anzeige (LED) und Verpolungsschutz
- LED: Light Emitting Diode



Quarz

- Symbol: Q
- Schaltzeichen: ⊣⊩
- liefert sehr stabile Referenzfrequenz
- Funktionsweise: Quarzplättchen mit angelegten Elektroden:
 - Quarz verbiegt sich beim Anlegen einer Spannung
 - Spannung weg → Deformation umgekehrt → Spannung wird produziert
 - positive Rückkoppelung nur bei Resonanzfrequenz und Harmonischen



- Elektronik
- Using Microcontrollers
 - What is an MCU?
 - ATMega8 features
 - Differences from coding on a PC
- Geekclock Hardware
- Geekclock Software

What is a microcontroller?

- Wikipedia: A microcontroller (or MCU) is a computer-on-a-chip. It is a type of microprocessor emphasizing self-sufficiency and cost-effectiveness, in contrast to a general-purpose microprocessor (the kind used in a PC).
- RAM, ROM, memory and a CPU are, along with various peripherals, all contained on a single chip, which can be programmed to fulfill a specific task.

ATMega8

- RISC Microcontroller, max 16MHz
- 23 I/O lines
- lots of integrated peripherals
 - timers
 - AD converters
 - PWM
 - internal or external oscillator possible
- sleep mode support
- In-System Programmable Flash memory

MCU coding peculiarities

- less powerful hardware
- in our case
 - 32kHz core frequency (up to 16MHz would be possible)
 - 1KB SRAM
 - 8KB Flash memory
 - ... ought to be enough for everyone
- no FPU



MCU coding peculiarities (continued)

- no OS
 - only one process
 - no virtual memory, etc
 - hard real time is possible
 - avr-libc provides some functions
- no printf
- no easy way to tell if an error is in software or in hardware
- programs are usually designed to never reach an end

some advice for efficient coding


- use gcc with -0s (-02 and optimize for size)
- don't use 32bit integers, when you only need 8bit (→ use uint8_t or int8_t) [demo]
- condition checks are preferable to expressions with modulo operations or multiplications
- avoid floating point variables and functions (sin(), sqrt(), ...)
- keep variable count low (even if the SRAM is big enough –
 if you have only a few variables, they can always stay in the
 registers)
- there is usually no need to code in assembler
- don't worry ... 32kHz is more than it might seem



- Elektronik
- Using Microcontrollers
- Geekclock Hardware
 - Hardware Overview
 - Circuit diagram
- Geekclock Software

Geekclock Hardware Overview

- core: ATMega8 MCU
- clock from 32kHz crystal (low frequency to save power)
- 6 LEDs to show time in binary
- button to control clock
- diode to protect MCU from wrong polarity
- interface for programming via LPT cable or USB programmer



- Elektronik
- Using Microcontrollers
- Geekclock Hardware
- Geekclock Software
 - Software concept
 - Structure Overview
 - Code Walkthrough

Software concept

- hardware timer generates interrupt each second
- time is updated in interrupt routine
- button generates interrupt
- time is shown in main routine after button was pressed

Structure overview

- geekclock.c: interrupts, main-routine
- lowlevel.c: initialisation (Timer, Ports), lowlevel functions
- datetime.c: calendar functions, time functions
- led.c: LED control, effects

Code

(Code)

Questions

Questions?

