Kaveri Precision Components Pvt. Ltd. - Hosur Plant

Lockout / Tagout (LOTO) - Safety Procedure

Document No.	SAF-SOP-003	Revision	05
Effective Date	12-Feb-2026	Page	See footer
Prepared By	J. Fathima, Safety Officer	Approved By	A. Krishnan, Plant Head

1. Purpose

To protect people from the unexpected start-up of machines or release of stored energy (electrical, hydraulic, pneumatic, mechanical) during maintenance, cleaning, setting or repair.

2. Scope

Applies to all employees and contract workers at the Hosur plant who maintain, clean or repair machines, including CNC turning centres, presses and compressors.

3. Definitions

- **Authorised person:** a trained employee who applies their own personal lock and tag to isolate energy.
- **Affected person:** an operator or employee who works in the area but does not perform the isolation.
- **Zero energy state:** the condition where all energy sources are isolated and stored energy is released, so that the machine cannot move or release energy.

4. Lockout Procedure

1. Inform all affected persons that the machine is being shut down for maintenance.
2. Stop the machine using the normal stop sequence.
3. Isolate all energy sources: main electrical isolator, compressed air valve, and hydraulic power unit.
4. Apply your **personal red lock and danger tag** to each isolation point. Each authorised person working on the machine applies their own lock. Use a multi-lock hasp when more than one person is involved.
5. Release stored energy: bleed hydraulic pressure and accumulators until the gauge reads **zero**, vent compressed air to 0 bar, and block any parts that can fall under gravity.
6. **Verify zero energy:** try to start the machine from the control panel and confirm it does not start. Confirm all pressure gauges read zero. Return controls to OFF.

5. Removing Locks

1. Check that tools and materials are removed and guards are refitted.
2. Confirm all persons are clear of the machine.
3. Each authorised person removes **only their own lock**. Nobody may remove another person's lock.
4. Inform affected persons that the machine is being restarted.

6. Removal of a Lock When the Owner Is Absent

If an authorised person has left the plant without removing their lock, the lock may be removed only through this procedure:

1. The Shift Supervisor makes every reasonable effort to contact the lock owner by phone.
2. If the owner cannot be reached, the Production Manager and the Safety Officer must **both** authorise removal.
3. The machine is physically inspected to confirm it is safe to re-energise.

4. The removal is recorded on form **SF-12 Lock Removal Record**.
5. The lock owner must be informed before they resume work on their next shift.

7. Training and Audits

- All authorised persons must complete LOTO training before applying locks, with refresher training every 12 months.
- The Safety Officer audits LOTO practice on each shift at least once a month.
- Violation of this procedure is treated as a serious safety breach.