



VASD

Vehicle Actuated Speed Display

Connection

Connect VASD with TCP/IP communication by using: Default IP: 192.168.0.7/8

Port: 23

Command For Entering Text

|T|0-0|99|1|7|1|0|/r/n

- | - Command separator T – For Text
- | - Command separator 0 – x position Fixed
- Pixel Separator
- 0 – y position Fixed
- | - Command separator 99 – text to print (0-99)
- | - command separator
- 1 – text color (please see the text color table)
- | - command separator 7 –font size Fixed
- | - command separator
- 1 – text effect (this is further bit you can used only 1)
- | - command separator
- 0 – text reserve (for further used you can used only 0)
- | - command separator /r- End string/n- New Line

Command For Clearing Text

|C|0-0|99|1|7|1|0|/r/n

- | - Command separator C – For Clear
- | - Command separator 0 – x position (0-127)
- Pixel Separator
- 40 – y position (0-127)
- | - Command separator HELLO – text to print.



| - command separator

1 – text color (please see the text color table)

| - command separator

2 –font size (please see the font table)

| - command separator

1 – text effect (this is further bit you can used only 1)

| - command separator

0 – text reserve (for further used you can used only 0)

| - command separator /r- End string/n- New Line

✦ Command For Full Display Clear

|C|0-0|CLEAR|0|0|1|0|\r\n

| - command separator C – for Clear Display

| - command separator 0 – x position start

- PIXEL_SEPARATOR

0 – y position start

CLEAR|0|0|1|0| To Clear the full display this value should not be changed.

• Color Table

Color Code Value	Color Name	REMARKS
1	RED,	
2	GREEN	
3	YELLOW	
4	BLUE	
5	MAGENTA	
6	CYAN	
7	WHITE	

Note: The value of x will change for single digit 0-9, the value of x will remain 0 for double digit printing on screen