

does not survive a reboot of one of the participants. Adjacent layers MAY close an Exchange at any time.

4.10.2. Exchange ID

An Exchange of messages is identified by the Exchange ID field described in [Section 4.4.3.3, “Exchange ID \(16 bits\)”](#). The Exchange ID is allocated by the Initiator. The first message the Initiator sends in a new Exchange SHALL contain a fresh value for the Exchange ID field. The Exchange is then identified by the tuple {[Session Context](#), [Exchange ID](#), [Exchange Role](#)} where Session Context is one of an [Unsecured](#), [Secured](#), [Groupcast](#) or [MCSP](#) session context. All messages that are part of a given Exchange, whether they are sent by the Initiator or not, share the same Exchange ID, allowing the Initiator and Responder Nodes to match responses to requests or otherwise group messages together that are part of more complex transactions. The first Exchange ID for a given Initiator Node SHALL be a random integer. All subsequent Exchange IDs created by that Initiator SHALL be the last Exchange ID it created incremented by one. An Exchange ID is an unsigned integer that rolls over to zero when its maximum value is exceeded.

4.10.3. Exchange Context

An Exchange context is the metadata tracked for an Exchange by all exchange participants. An Exchange context tracks the following data:

1. [Exchange ID](#): The Exchange ID assigned by the Initiator
2. [Exchange Role](#): Initiator or Responder
3. [Session Context](#): The underlying [Unsecured](#), [Secured](#), [Groupcast](#) or [MCSP](#) session context
 - Together, Session Context, Exchange ID and Role comprise a unique key allowing participants to identify any exchange.

4.10.3.1. Protocol ID Registration

The Interaction Model layer indicates to the Exchange Layer which [Protocols](#) it will accept. Any message for a [Protocol ID](#) that is not registered with the Exchange Layer SHALL be dropped.

4.10.4. Exchange Message Dispatch

When sending a message to the Exchange Layer, the next higher layer SHALL specify whether the message is part of an existing Exchange, or the first of a new Exchange. For the case of a first message, the Initiator creates a new Exchange. The Node in the Initiator role SHALL always set the [I Flag](#) in the [Exchange Flags](#) of every message it sends in that Exchange.

Each Node in a Responder role for an Exchange SHALL use the Exchange ID received in previous messages for the Exchange. Each Node in the Responder role SHALL NOT set the [I Flag](#) in the [Exchange Flags](#) of every message it sends in that Exchange. Each Node in a Responder role SHALL NOT set the [Destination Node ID](#) field to a value that identifies any Node other than the Node in the Initiator role for the Exchange.

Processing SHALL then proceed to [Section 4.12.5.1, “Reliable Message Processing of Outgoing Messages”](#).