

log to the user. This field SHALL NOT be set when the CommissionerPasscode field is set since these two functionalities are mutually exclusive.

6. When using a Commissionee-generated Passcode, to indicate the length of the Passcode displayed to the user by the Commissionee:
 - a. Construct the **PasscodeLength** and set to the length of the displayed Passcode.
7. To optionally request a Commissioner-generated Passcode from a Commissioner which indicates support for this feature via the **CP TXT record** in **Commissionable Node Discovery**:
 - a. Construct the **CommissionerPasscode** and set to true. When this field is set to true in the IdentificationDeclaration message, the Commissioner SHOULD display the commissioning Passcode to the user, and wait to initiate commissioning until an IdentificationDeclaration message is received with the **CommissionerPasscodeReady** field set to true.
 - b. Construct the **CommissionerPasscodeReady** and set to true to indicate the Commissionee has obtained the Commissioner Passcode from the user and is ready for commissioning, or false to indicate that the user has not entered the Passcode yet, and therefore, the Commissioner SHOULD NOT commence commissioning.
8. To optionally indicate that the Commissionee user has cancelled the commissioning process:
 - a. Construct the **CancelPasscode** and set to true. This indicates that the Commissioner can dismiss any dialogs corresponding to commissioning, such as a Passcode input dialog or a Passcode display dialog.
9. Construct and send **IdentificationDeclaration**.

5.3.6. CommissionerDeclaration Message

This message is sent by a Commissioner to a Commissionee in response to a IdentificationDeclaration message. The CommissionerDeclaration provides information indicating the Commissioner's pre-commissioning state.

```
CommissionerDeclaration-struct => STRUCTURE [ tag-order ]
{
  ErrorCode                [1, optional] : UNSIGNED INTEGER [ range 16-bits ],
  NeedsPasscode            [2, optional] : BOOLEAN,
  NoAppsFound              [3, optional] : BOOLEAN,
  PasscodeDialogDisplayed  [4, optional] : BOOLEAN,
  CommissionerPasscode     [5, optional] : BOOLEAN,
  QRCodeDisplayed          [6, optional] : BOOLEAN,
  CancelPasscode           [7, optional] : BOOLEAN,
  PasscodeLength           [8, optional] : UNSIGNED INTEGER [ range 8-bits ]
}
```

5.3.6.1. Parameters

This following table lists the parameters used in IdentificationDeclaration with a brief description for each parameter and the feature that uses it.