

The new Administrator's Commissioner then completes commissioning with the Node using similar Commissioning flow as it would do for a factory-new device (although note that IP channel is used for discovery). It can either read the QR code format or NFC tag, or use the Manual Pairing Code format of the [Onboarding Payload](#) of the Node.

The following steps describe a possible sequence of events for BCM commissioning:

1. Current Administrator puts the Node in [OpenBasicCommissioningWindow](#) for a specified time window, and receives success response from the Node on the [OpenBasicCommissioningWindow](#) command.
  - a. When the targeted Node is a [ICD](#), the current Administrator can guide the user to perform some action to 'wake' the device from its sleep cycle.
2. New Administrator completes commissioning within the prescribed window using steps outlined in [Figure 45, "Commissioning flow diagram"](#).

### 5.6.3. Enhanced Commissioning Method (ECM)

This method SHALL be implemented for Nodes and Commissioners/Administrators. When using ECM, the Node's current Administrator instructs the Node over a [CASE](#) session, to go into [OpenCommissioningWindow](#). It SHALL choose a new [RANDOM](#) passcode and SHALL compute and send the corresponding [PAKE](#) passcode verifier to the Node. Actual value of the passcode SHALL NOT be sent to the Node.

The current Administrator then presents the new passcode and discriminator as described [below](#). The Node SHALL advertise its presence over DNS-SD (see [Section 5.4.2.7, "Using Existing IP-bearing Network"](#) and [Section 4.3.1, "Commissionable Node Discovery"](#)) after receiving the [OpenCommissioningWindow](#) command.

#### 5.6.3.1. Presentation of Onboarding Payload for ECM

Presentation of the passcode and other relevant information SHALL be done at least with one or more of the methods below, depending on the capabilities of the first Administrator opening the OCW:

1. If a user interface display is supported, the temporary Onboarding Payload SHALL be displayed using a textual representation of the Manual Pairing Code, using the [11-digit variant](#): it SHALL NOT contain the [VENDOR\\_ID](#) or [PRODUCT\\_ID](#) as the commissioning of the node(s) using the ECM cannot be subject to User-Intent or Custom Flows.
2. If a user interface display is supported, the temporary Onboarding Payload SHOULD also be displayed using the definitions included in [Section 5.1.3, "QR Code"](#) subject to the following constraints:
  - a. If only a single Node is being subjected to the ECM, the Vendor ID and Product ID in the [onboarding payload](#) SHALL be the same as those of that Node.
  - b. If multiple Nodes are being subjected to the ECM using the same [onboarding payload](#), the Vendor ID SHALL be set to [0x0000](#) (Matter Standard) and the Product ID SHALL be set to [0x0000](#) (consistent with the value used for *not* advertising a Product ID in [Device Announcement](#)).