

[Reset Hint Values](#)”). If a Device Manufacturer setup artifact is required for this, beyond documentation, then the device is a [Section 5.7.3, “Custom Commissioning Flow”](#) device and not a User-Intent Commissioning Flow device. The documentation MAY be printed or in the form of online documentation (e.g. [Section 11.23.6.15, “UserManualUrl”](#)).

- A User-Intent Commissioning Flow device SHALL follow the rules for [Manual Pairing Code and QR Code Inclusion](#).
- The [Section 11.23, “Distributed Compliance Ledger”](#) entries for User-Intent Commissioning Flow devices SHALL include the [Section 11.23.6.8, “CommissioningCustomFlow”](#) field set to '1 - User Intent' and the [Section 11.23.6.10, “CommissioningModeInitialStepsHint”](#) field set to a non-zero integer value. Bit 0 (Power Cycle) in the [Section 11.23.6.10, “CommissioningModeInitialStepsHint”](#) field SHALL be set to 0. The [Section 11.23.6.11, “CommissioningModeInitialStepsInstruction”](#) field SHALL be set when CommissioningModeInitialStepsHint has a Pairing Instruction dependency and MAY be set when CommissioningModeInitialStepsHint has an optional Pairing Instruction dependency.
- A User-Intent Commissioning Flow device SHALL set [Custom Flow bits](#) in the Onboarding Payload to indicate '1 - User Intent'.
- The commissioner SHOULD reference [Distributed Compliance Ledger](#) fields such as [Section 11.23.6.10, “CommissioningModeInitialStepsHint”](#), [Section 11.23.6.11, “CommissioningModeInitialStepsInstruction”](#), UserManualUrl, and SupportUrl to assist the user during commissioning, e.g. to explain how to bring the device into commissioning mode.

Table 79. Values of Ledger fields to represent User-Intent Commissioning Flow

Field Name	Value(s)
CommissioningCustomFlow	1 - User Intent (Mandatory)
CommissioningModeInitialStepsHint	This field SHALL be set to a non-zero integer value. See Table 5, “Pairing and Reset Hint Values” for a complete list of pairing instructions. Example value: 96 - The following bits are set: 6 (Press Reset Button - Optional), 5 (Device Manual - Optional). Bit 1 (Device Manufacturer URL) MAY be set.
CommissioningModeInitialStepsInstruction	The field SHALL be set when CommissioningModeInitialStepsHint has a mandatory Pairing Instruction dependency and MAY be set when CommissioningModeInitialStepsHint has an optional Pairing Instruction dependency. See PI Dependency column of Pairing Hint Table to determine which pairing hints have a mandatory or optional Pairing Instruction dependency and therefore require or allow this field to be populated.