

sending a [RemoveNetwork](#). The Administrator SHALL provide the new credentials of the operational network to the Recovery Node using the [AddOrUpdateWiFiNetwork](#) or [AddOrUpdateThreadNetwork](#) commands.

13. The Administrator SHALL then instruct the Recovery Node to connect to the operational network using the new credentials by issuing a [ConnectNetwork](#) command.
14. The Recovery Node SHALL attempt to connect to the operational network using the newly-provisioned credentials. Once connected, all messages associated with the remaining Network Recovery steps between the Administrator and Recovery Node SHALL be exchanged over the operational network. These messages SHALL be communicated over a [CASE](#) session.
15. The Administrator and the Recovery Node SHALL discover each other on the operational network using operational discovery (see [Section 4.3.2, “Operational Discovery”](#)).
16. The Administrator and the Recovery Node SHALL indicate successful completion of the Network Recovery flow using the [CommissioningComplete](#) and [CommissioningCompleteResponse](#) commands. These commands SHALL be sent over a CASE session over the operational network. The Recovery Node SHALL reject the [CommissioningComplete](#) that is not received over the operational network.