

generated and submitted to the message layer to send to the initiator, otherwise no Write Response SHALL be sent.

8.7.3. Write Response Action

This action is a following action for a Write Request action. See [Section 8.2.5, “Common Action Behavior”](#) for behavior common to all actions. The specific action information for this action is shown below.

8.7.3.1. Write Response Action Information

Action Field	Type	Conformance	Description
WriteResponses	list[AttributeStatusIB]	O	a list of zero or more concrete paths indicating errors or successes

8.7.3.2. Outgoing Write Response Action

- This action SHALL be unicast.
- Each request path in the WriteRequests field of a Write Request SHALL be processed as follows:
 - If the path does not conform to [Valid Write Attribute Paths](#) then:
 - a Status Response with the INVALID_ACTION Status Code SHALL be generated as defined in [Status Response Action](#), a Write Response action SHALL NOT be generated, and this interaction and process SHALL terminate.
 - Else if the path is a concrete path, the path SHALL be processed as follows, terminating further processing of the concrete path immediately if a failure [AttributeStatusIB](#) is generated at any point (one that is not a status of SUCCESS).
 - Execute the [ACL Access Granting Algorithm](#) against the concrete path, assuming the **required_privilege** for the element is View, to determine whether the subject would have had at least some access against the concrete path.
 - If the outcome is AccessDenied, an [AttributeStatusIB](#) SHALL be generated with the UNSUPPORTED_ACCESS Status Code.
 - Else if the outcome is AccessRestricted, an [AttributeStatusIB](#) SHALL be generated with the ACCESS_RESTRICTED Status Code.
 - Otherwise, continue processing.
 - Determine element existence from the concrete path, and apply the following checks:
 - If the path indicates a node that is unsupported, an [AttributeStatusIB](#) SHALL be generated with the UNSUPPORTED_NODE Status Code.
 - Else if the path indicates an endpoint that is unsupported, an [AttributeStatusIB](#) SHALL be generated with the UNSUPPORTED_ENDPOINT Status Code.
 - Else if the path indicates a cluster that is unsupported, an [AttributeStatusIB](#) SHALL be generated with the UNSUPPORTED_CLUSTER Status Code.
 - Else if the path indicates an attribute or attribute data field that is unsupported, an