

Status Code	Value	Summary
0xD0	ALREADY_EXISTS	Attempt to create an entity that already exists or create an entity with an identifier that is already in use. Command or action not carried out.
0xD1	INVALID_TRANSPORT_TYPE	Attempt to process on a transport type not valid for this element. Command or action not carried out.