

5. the Groups Cluster (0x0004)

In addition, use of this feature SHALL NOT restrict the [global attributes](#) of any cluster.

Because ARLs cannot be used to restrict root node access or access to any clusters required for commissioning, administrators MAY determine the current restrictions of the ARL at any point, including during commissioning after joining the fabric.

9.10.5. Data Types

9.10.5.1. ChangeTypeEnum Type

This data type is derived from [enum8](#).

Value	Name	Summary	Conformance
0	Changed	Entry or extension was changed	M
1	Added	Entry or extension was added	M
2	Removed	Entry or extension was removed	M

9.10.5.2. AccessControlEntryPrivilegeEnum Type

This data type is derived from [enum8](#).

Value	Name	Summary	Conformance
1	View	Can read and observe all (except Access Control Cluster)	M
2	Proxy View		D
3	Operate	View privileges, and can perform the primary function of this Node (except Access Control Cluster)	M
4	Manage	Operate privileges, and can modify persistent configuration of this Node (except Access Control Cluster)	M
5	Administer	Manage privileges, and can observe and modify the Access Control Cluster	M