

provide a UniqueID attribute), the bridge SHALL generate a unique id on behalf of the bridged device.

NOTE The UniqueID attribute was optional in cluster revisions prior to revision 4.

9.13.5.4. ConfigurationVersion Attribute

This attribute SHALL contain the current version number for the configuration of the bridged device. A larger value of ConfigurationVersion SHALL indicate a newer configuration than a lower value.

If the bridge detects a change on a bridged device, which it deems as a change in the configuration of the bridged device, it SHALL increase this attribute (and the corresponding attribute on the bridge itself) as described in [Section 9.2.11, “Node Configuration Changes”](#).

The ability and the method used to detect such a change on a bridged device is manufacturer specific.

9.13.6. Commands

ID	Name	Direction	Response	Access	Conformance
0x80	KeepActive	client ⇒ server	Y	O	BIS

9.13.6.1. KeepActive Command

Upon receipt, the server SHALL attempt to keep the bridged device active for the duration specified by the command, when the device is next active.

The implementation of this is best-effort since it may interact with non-native protocols. However, several specific protocol requirements are:

- If the bridged device is a Matter Intermittently Connected Device, then the server SHALL send a [StayActiveRequest](#) command with the StayActiveDuration field set to value of the StayActiveDuration field in the received command to the bridged device when the bridged device next sends a checks-in message or subscription report. See [Intermittently Connected Devices Behavior](#) for details on ICD state management.

When the bridge detects that the bridged device goes into an active state, an ActiveChanged event SHALL be generated.

In order to avoid unnecessary power consumption in the bridged device:

- The server SHALL enter a "pending active" state for the associated device when the KeepActive command is received. The server "pending active" state SHALL expire after the amount of time defined by the TimeoutMs field, in milliseconds, if no subsequent KeepActive command is received. When a KeepActive command is received, the "pending active" state is set, the StayActiveDuration is updated to the greater of the new value and the previously stored value, and the TimeoutMs is updated to the greater of the new value and the remaining time until the prior "pending active" state expires.