

| ID | Name                   | Type    | Constraint | Quality | Fallback | Conformance |
|----|------------------------|---------|------------|---------|----------|-------------|
| 0  | <b>CheckInNodeID</b>   | node-id | all        |         |          | M           |
| 1  | <b>VerificationKey</b> | octstr  | 16         |         |          | O           |

#### CheckInNodeID Field

This field SHALL provide the registered client node ID to remove from storage.

#### VerificationKey Field

This field SHALL provide the verification key associated with the CheckInNodeID to remove from storage. The verification key represents the key already stored on the server. The verification key provided in this field SHALL be used by the server to guarantee that a client with manage permissions can only remove entries that contain a Key equal to the stored key. The verification key SHALL be provided for clients with manage permissions. The verification key SHOULD NOT be provided by clients with administrator permissions for the server cluster. The verification key SHALL be ignored by the server if it is provided by a client with administrator permissions for the server cluster.

#### Effect on Receipt

On receipt of the UnregisterClient command, the server SHALL perform the following procedure:

1. The server SHALL check whether there is a entry stored on the device for the fabric with the same CheckInNodeID.
  - a. If there are no entries stored for the fabric, the status SHALL be NOT\_FOUND. The server SHALL continue from step 6.
  - b. If there is an error when reading from storage, the status SHALL be FAILURE. The server SHALL continue from step 6.
  - c. If there is at least one entry stored on the server for the fabric, the server SHALL continue from step 2.
2. The server SHALL verify if one of the entries for the fabric has the corresponding CheckInNodeID received in the command.
  - a. If no entries have the corresponding CheckInNodeID, the status SHALL be NOT\_FOUND. The server SHALL continue from step 6.
  - b. If an entry has the corresponding CheckInNodeID, the server SHALL continue to step 3.
3. The server SHALL check whether the **ISD** of the command has administrator permissions for the server cluster.
  - a. If the **ISD** of the command has administrator privileges for the server cluster, the server SHALL continue from step 5.
  - b. If the **ISD** of the command does not have administrator privileges for the server cluster, the server SHALL continue from step 4.