

Value	Name	Summary	Conformance
0	Unknown	Unable to determine the charging state	M
1	IsCharging	The battery is charging	M
2	IsAtFullCharge	The battery is at full charge	M
3	IsNotCharging	The battery is not charging	M

11.7.7. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Status	Power-SourceStatusEnum	desc			R V	M
0x0001	Order	uint8	all	N		R V	M
0x0002	Description	string	max 60	F		R V	M
0x0003	WiredAssessedInput-Voltage	uint32	all	C X		R V	[WIRED]
0x0004	WiredAssessedInput-Frequency	uint16	all	C X		R V	[WIRED]
0x0005	WiredCurrentType	WiredCurrentTypeEnum	desc	F		R V	WIRED
0x0006	WiredAssessedCurrent	uint32	all	C X		R V	[WIRED]
0x0007	Wired-Nominal-Voltage	uint32	all	F		R V	[WIRED]
0x0008	Wired-MaximumCurrent	uint32	all	F		R V	[WIRED]
0x0009	WiredPresent	bool	all			R V	[WIRED]