

11.7.7.27. **BatChargeState Attribute**

This attribute SHALL indicate the current state of the battery source with respect to charging as specified in [BatChargeStateEnum](#).

11.7.7.28. **BatTimeToFullCharge Attribute**

This attribute SHALL indicate the estimated time in seconds before the battery source will be at full charge. A value of NULL SHALL indicate the Node is currently unable to assess the value.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- At most once every 10 seconds, or
- When it changes from null to any other value and vice versa.

Since reporting consumes power, devices SHOULD be careful not to over-report.

11.7.7.29. **BatFunctionalWhileCharging Attribute**

This attribute SHALL indicate whether the Node can remain operational while the battery source is charging.

11.7.7.30. **BatChargingCurrent Attribute**

This attribute SHALL indicate assessed current in mA (milliamps) presently supplied to charge the battery source. A value of NULL SHALL indicate the Node is currently unable to assess the value.

11.7.7.31. **ActiveBatChargeFaults Attribute**

This attribute SHALL indicate the set of charge faults currently detected by the Node on this power source. This set is represented as a list of [BatChargeFaultEnum](#). When the Node detects a fault has been raised, the appropriate [BatChargeFaultEnum](#) value SHALL be added to this list, provided it is not already present. This list SHALL NOT contain more than one instance of a specific [BatChargeFaultEnum](#) value. When the Node detects all conditions contributing to a fault have been cleared, the corresponding [BatChargeFaultEnum](#) value SHALL be removed from this list. An empty list SHALL indicate there are currently no active faults. The order of this list SHOULD have no significance. Clients interested in monitoring changes in active faults MAY subscribe to this attribute, or they MAY subscribe to the [BatFaultChange event](#).

11.7.7.32. **EndpointList Attribute**

This attribute SHALL indicate a list of endpoints that are powered by the source defined by this cluster. Multiple instances of this cluster MAY list the same endpoint, because it is possible for power for an endpoint to come from multiple sources. In that case the Order attribute indicates their priority.

For each power source on a node, there SHALL only be one instance of this cluster.

A cluster instance with an empty list SHALL indicate that the power source is for the entire node, which includes all endpoints.