

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0008	Supported-WiFiBands	list[WiFiBandEnum]	min 1	F	MS	R V	WI
0x0009	SupportedThreadFeatures	ThreadCapabilitiesBitmap		F	MS	R V	TH
0x000A	Thread-Version	uint16		F	MS	R V	TH

11.9.6.1. MaxNetworks Attribute

This SHALL indicate the maximum number of network configuration entries that can be added, based on available device resources. The length of the [Networks](#) attribute SHALL be less than or equal to this value.

11.9.6.2. Networks Attribute

This attribute SHALL indicate the network configurations that are usable on the network interface represented by this cluster server instance.

The order of configurations in the list reflects precedence. That is, any time the Node attempts to connect to the network it SHALL attempt to do so using the configurations in Networks Attribute in the order as they appear in the list.

The order of list items SHALL only be modified by the AddOrUpdateThreadNetwork, AddOrUpdateWiFiNetwork and ReorderNetwork commands. In other words, the list SHALL be stable over time, unless mutated externally.

Ethernet networks SHALL be automatically populated by the cluster server. Ethernet Network Commissioning Cluster instances SHALL always have exactly one [NetworkInfoStruct](#) instance in their [Networks](#) attribute. There SHALL be no way to add, update or remove Ethernet network configurations to those Cluster instances.

11.9.6.3. ScanMaxTimeSeconds Attribute

This attribute SHALL indicate the maximum duration taken, in seconds, by the network interface on this cluster server instance to provide scan results.

See [Section 11.9.7.1, “ScanNetworks Command”](#) for usage.

11.9.6.4. ConnectMaxTimeSeconds Attribute

This attribute SHALL indicate the maximum duration taken, in seconds, by the network interface on this cluster server instance to report a successful or failed network connection indication. This maximum time SHALL account for all operations needed until a successful network connection is