

ID	Name	Direction	Response	Access	Conformance
0x03	AddOrUpdateThreadNetwork	client ⇒ server	NetworkConfigResponse	A	TH
0x04	RemoveNetwork	client ⇒ server	NetworkConfigResponse	A	WI TH
0x05	NetworkConfigResponse	client ⇐ server	N		WI TH
0x06	ConnectNetwork	client ⇒ server	ConnectNetworkResponse	A	WI TH
0x07	ConnectNetworkResponse	client ⇐ server	N		WI TH
0x08	ReorderNetwork	client ⇒ server	NetworkConfigResponse	A	WI TH

11.9.7.1. ScanNetworks Command

This command is used to scan for available networks on the network interface associated with the cluster instance.

This command SHALL scan on the Cluster instance's associated network interface for either of:

- All available networks (non-directed scanning)
- Specific networks (directed scanning)

Scanning for available networks detects all networks of the type corresponding to the cluster server instance's associated network interface that are possible to join, such as all visible Wi-Fi access points for Wi-Fi cluster server instances, all Thread PANs for Thread cluster server instances, within bounds of the maximum response size.

Scanning for a specific network (i.e. directed scanning) takes place if a network identifier (e.g. Wi-Fi SSID) is provided in the command arguments. Directed scanning SHALL restrict the result set to the specified network only.

If this command is received without an armed fail-safe context (see [Section 11.10.7.2, “ArmFail-Safe”](#)), then this command SHALL fail with a FAILSAFE_REQUIRED status code sent back to the initiator.

The client SHALL NOT expect the server to be done scanning and have responded with ScanNetworksResponse before [ScanMaxTimeSeconds](#) seconds have elapsed. Enough transport time affordances for retries SHOULD be expected before a client determines the operation to have timed-out.

This command SHALL fail with a status code of BUSY if the server determines that it will fail to reliably send a response due to changes of networking interface configuration at runtime for the interface over which the command was invoked, or if it is currently unable to proceed with such an operation.