

Breadcrumb Field

See [Section 11.9.7.1.2, “Breadcrumb Field”](#) for usage.

11.9.7.9. ConnectNetworkResponse Command

This command is used to report the results of a ConnectNetwork command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NetworkingStatus	NetworkCommissioningStatusEnum	all			M
1	DebugText	string				O
2	ErrorValue	int32	all	X		M

Before generating a ConnectNetworkResponse, the server SHALL:

- Set the [LastNetworkingStatus](#) attribute value to the NetworkingStatus matching the response.
- Set the [LastNetworkID](#) attribute value to the NetworkID that was used in the ConnectNetwork command which caused the response to be generated.
- Set the [LastConnectErrorValue](#) attribute value to the ErrorValue matching the response, including setting it to null if the ErrorValue is not applicable.

NetworkingStatus Field

The NetworkingStatus field SHALL indicate the status of the last connection attempt, taking one of these values:

- Success: Connection succeeded.
- [NetworkNotFound](#): No instance of an explicitly-provided network identifier was found during the attempt to join the network.
- [OutOfRange](#): Network identifier was invalid (e.g. empty, too long, etc).
- [NetworkIdNotFound](#): The network identifier was not found among the added network configurations in [Networks](#) attribute.
- [RegulatoryError](#): Could not connect to a network due to lack of regulatory configuration.
- [UnknownError](#): An internal error occurred during the operation.
- Association errors (see also description of errors in [NetworkCommissioningStatusEnum](#)): [AuthFailure](#), [UnsupportedSecurity](#), [OtherConnectionFailure](#), [IPV6Failed](#), [IPBindFailed](#)

DebugText Field

See [Section 11.9.7.2.2, “DebugText Field”](#) for usage.