

ID	Name	Direction	Response	Access	Conformance
0x04	Payload-TestResponse	server ⇒ client	N		DMTEST

11.12.7.1. TestEventTrigger Command

This command SHALL be supported to provide a means for certification tests to trigger some test-plan-specific events, necessary to assist in automation of device interactions for some certification test cases. This command SHALL NOT cause any changes to the state of the device that persist after the last fabric is removed.

The fields for the TestEventTrigger command are as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	EnableKey	octstr	16			M
1	EventTrigger	uint64				M

EnableKey Field

The EnableKey is a 128 bit value provided by the client in this command, which needs to match a value chosen by the manufacturer and configured on the server using manufacturer-specific means, such as pre-provisioning. The value of all zeroes is reserved to indicate that no EnableKey is set. Therefore, if the EnableKey field is received with all zeroes, this command SHALL FAIL with a response status of CONSTRAINT_ERROR.

The EnableKey SHOULD be unique per exact set of devices going to a certification test.

Devices not targeted towards going to a certification test event SHALL NOT have a non-zero EnableKey value configured, so that only devices in test environments are responsive to this command.

In order to prevent unwittingly actuating a particular trigger, this command SHALL respond with a response status of CONSTRAINT_ERROR if the EnableKey field does not match the a-priori value configured on the device.

EventTrigger Field

This field SHALL indicate the test or test mode which the client wants to trigger.

The expected side-effects of EventTrigger values are out of scope of this specification and will be described within appropriate certification test literature provided to manufacturers by the Connectivity Standards Alliance, in conjunction with certification test cases documentation.

Values of EventTrigger in the range 0xFFFF_FFFF_0000_0000 through 0xFFFF_FFFF_FFFF_FFFF are reserved for testing use by manufacturers and will not appear in the Connectivity Standards Alliance certification test literature.