

**StackSize Field**

The StackSize field SHALL indicate the amount of stack memory, in bytes, that has been allocated for use by the respective thread.

**11.13.6. Attributes**

| ID     | Name                            | Type                                      | Constraint | Quality | Fallback | Access | Conformance |
|--------|---------------------------------|-------------------------------------------|------------|---------|----------|--------|-------------|
| 0x0000 | <b>Thread-Metrics</b>           | <a href="#">list[ThreadMetricsStruct]</a> | max 64     |         |          | R V    | O           |
| 0x0001 | <b>CurrentHeapFree</b>          | uint64                                    |            |         |          | R V    | O           |
| 0x0002 | <b>CurrentHeapUsed</b>          | uint64                                    |            |         |          | R V    | O           |
| 0x0003 | <b>CurrentHeapHighWatermark</b> | uint64                                    |            |         |          | R V    | WTRMRK      |

**11.13.6.1. ThreadMetrics Attribute**

This attribute SHALL be a list of [ThreadMetricsStruct](#) structs. Each active thread on the Node SHALL be represented by a single entry within the ThreadMetrics attribute.

**11.13.6.2. CurrentHeapFree Attribute**

This attribute SHALL indicate the current amount of heap memory, in bytes, that are free for allocation. The effective amount MAY be smaller due to heap fragmentation or other reasons.

**11.13.6.3. CurrentHeapUsed Attribute**

This attribute SHALL indicate the current amount of heap memory, in bytes, that is being used.

**11.13.6.4. CurrentHeapHighWatermark Attribute**

This attribute SHALL indicate the maximum amount of heap memory, in bytes, that has been used by the Node. This value SHALL only be reset upon a Node reboot or upon receiving of the [ResetWatermarks](#) command.

**11.13.7. Commands**