

ID	Name	Direction	Response	Access	Conformance
0x00	ResetWatermarks	client ⇒ server	Y	M	WTRMRK

11.13.7.1. ResetWatermarks Command

This command is used to reset the high watermarks for heap and stack memory.

Receipt of this command SHALL reset the following values which track high and lower watermarks:

- The StackFreeMinimum field of the [ThreadMetrics](#) attribute
- The [CurrentHeapHighWatermark](#) attribute

Effect on Receipt

On receipt of this command, the Node SHALL make the following modifications to attributes it supports:

If implemented, the server SHALL set the value of the [CurrentHeapHighWatermark](#) attribute to the value of the CurrentHeapUsed attribute.

If implemented, the server SHALL set the value of the [StackFreeMinimum](#) field for every thread to the value of the corresponding thread's [StackFreeCurrent](#) field.

11.13.8. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	SoftwareFault	INFO		V	O

11.13.8.1. SoftwareFault Event

This Event SHALL be generated when a software fault occurs on the Node.

The event's data are as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ID	uint64	all		0	M
1	Name	string	max 8		empty	O
2	Fault-Recording	octstr	max 1024		empty	O

ID Field

This field SHALL be set to the ID of the software thread in which the last software fault occurred.