

ID	Name	Priority	Quality	Access	Conformance
0x02	Connection-Status	info		V	O

11.15.8.1. Disconnection Event

The Disconnection Event SHALL indicate that a Node's Wi-Fi connection has been disconnected as a result of de-authenticated or dis-association and indicates the reason.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ReasonCode	uint16				M

ReasonCode Field

This field SHALL contain the Reason Code field value for the Disassociation or Deauthentication event that caused the disconnection and the value SHALL align with Table 9-49 "Reason codes" of [IEEE 802.11-2020](#).

11.15.8.2. AssociationFailure Event

The AssociationFailure event SHALL indicate that a Node has attempted to connect, or reconnect, to a Wi-Fi access point, but is unable to successfully associate or authenticate, after exhausting all internal retries of its supplicant.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Association-Failure-Cause	Association-Failure-CauseEnum	all			M
1	Status	uint16	all			M

AssociationFailureCause Field

The Status field SHALL be set to a value from the [AssociationFailureCauseEnum](#).

Status Field

The Status field SHALL be set to the Status Code value that was present in the last frame related to association where Status Code was not equal to zero and which caused the failure of a last trial attempt, if this last failure was due to one of the following Management frames:

- Association Response (Type 0, Subtype 1)
- Reassociation Response (Type 0, Subtype 3)
- Authentication (Type 0, Subtype 11)

Table 9-50 "Status codes" of [IEEE 802.11-2020](#) contains a description of all values possible.