

offset of the currently valid [DSTOffsetStruct](#) from the [DSTOffset](#) attribute (converted to microseconds), if such an entry exists.

If the node has not achieved time synchronization, this SHALL be null. If the node has an empty [DSTOffset](#), this SHALL be null.

11.17.8.9. TimeZoneDatabase Attribute

This attribute SHALL indicate whether the node has access to a time zone database. Nodes with a time zone database MAY update their own [DSTOffset](#) attribute to add new entries and MAY push [DSTOffset](#) updates to other Nodes in the same time zone as required.

11.17.8.10. NTPServerAvailable Attribute

This attribute SHALL indicate if the node is running an [RFC 5905](#) NTPv4 compliant server on port 123, this value SHALL be True.

If the node is not currently running an NTP server, this value SHALL be False.

11.17.8.11. TimeZoneListMaxSize Attribute

This attribute SHALL indicate the number of supported list entries in the [TimeZone](#) attribute. This attribute may take the value of 1 or 2, where the optional second list entry MAY be used to handle scheduled regulatory time zone changes.

11.17.8.12. DSTOffsetListMaxSize Attribute

This attribute SHALL indicate the number of supported list entries in [DSTOffset](#) attribute. This value must be at least 1.

11.17.8.13. SupportsDNSResolve Attribute

This attribute SHALL indicate if the node supports resolving a domain name. DefaultNTP Address values for these nodes MAY include domain names. If this is False, the Address for a DefaultNTP SHALL be an IPv6 address.

11.17.9. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	SetUTCTime	client ⇒ server	Y	A	M
0x01	SetTrusted-TimeSource	client ⇒ server	Y	A F	TSC
0x02	SetTimeZone	client ⇒ server	SetTime-ZoneResponse	M	TZ
0x03	SetTime-ZoneResponse	client ⇐ server	N		TZ
0x04	SetDSTOffset	client ⇒ server	Y	M	TZ