

11.19.6. Status Codes

11.19.6.1. StatusCodeEnum Type

This data type is derived from [enum8](#).

Value	Name	Summary	Conformance
0x02	Busy	Could not be completed because another commissioning is in progress	M
0x03	PAKEParameterError	Provided PAKE parameters were incorrectly formatted or otherwise invalid	M
0x04	WindowNotOpen	No commissioning window was currently open	M

11.19.7. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Window-Status	Commissioning-Window-StatusEnum				R V	M
0x0001	Admin-FabricIndex	fabric-idx		X		R V	M
0x0002	Admin-VendorId	vendor-id		X		R V	M

11.19.7.1. WindowStatus Attribute

This attribute SHALL indicate whether a new Commissioning window has been opened by an Administrator, using either the [OpenCommissioningWindow](#) command or the [OpenBasicCommissioningWindow](#) command.

This attribute SHALL revert to WindowNotOpen upon expiry of a commissioning window.

NOTE

An initial commissioning window is not opened using either the [OpenCommissioningWindow](#) command or the [OpenBasicCommissioningWindow](#) command, and therefore this attribute SHALL be set to WindowNotOpen on initial commissioning.