

of DatastoreEndpointBindingEntryStruct.

This field is used to uniquely identify an entry in the EndpointBindingList attribute for the purpose of deletion (RemoveBindingFromEndpointForNode Command).

Binding Field

The binding target structure.

StatusEntry Field

Indicates whether entry in this list is pending, committed, delete-pending, or commit-failed.

11.24.5.8. DatastoreEndpointGroupIDEntryStruct Type

ID	Name	Type	Constraint	Quality	Default	Access	Conformance
0	NodeID	node-id	all			R V	M
1	End-pointID	endpoint-no	all			R V	M
2	GroupID	group-id	all			R V	M
3	StatusEntry	DatastoreStatusEntryStruct				R V	M

NodeID Field

The unique identifier for the node.

EndpointID Field

The unique identifier for the endpoint.

GroupID Field

The unique identifier for the group.

StatusEntry Field

Indicates whether entry in this list is pending, committed, delete-pending, or commit-failed.

11.24.5.9. DatastoreEndpointEntryStruct Type

The DatastoreEndpointEntryStruct represents an Endpoint on a specific Node which is managed by the Datastore. Only Nodes on the Joint Fabric are managed by the Datastore. As a result, references to NodeID are specific to the Joint Fabric.