

ID	Name	Type	Constraint	Quality	Fallback	Conformance
1	Friendly-Name	string	max 32			M

NodeID represents the node to be updated in the [Joint Fabric](#) Datastore Cluster.

If a Node Information Entry does not exist for the given NodeID, this command SHALL return NOT_FOUND.

11.24.7.13. RemoveNode Command

This command SHALL be used to remove a node from the [Joint Fabric](#) Datastore Cluster of the accessing fabric.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NodeID	node-id	all			M

NodeID represents the unique identifier for the node to be removed from the [Joint Fabric](#) Datastore Cluster.

If a Node Information Entry does not exist for the given NodeID, this command SHALL return NOT_FOUND.

11.24.7.14. UpdateEndpointForNode Command

This command SHALL be used to update the state of an endpoint for a node in the [Joint Fabric](#) Datastore Cluster of the accessing fabric.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	EndpointID	endpoint-no	all			M
1	NodeID	node-id	all			M
2	Friendly-Name	string	max 32			M

EndpointID represents the unique identifier for the endpoint to be updated in the [Joint Fabric](#) Datastore Cluster.

NodeID represents the unique identifier for the node to which the endpoint belongs.

If an Endpoint Information Entry does not exist for the given NodeID and EndpointID, this command SHALL return NOT_FOUND.