

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NodeID	node-id	all			M
1	EndpointID	endpoint-no	all			M
2	Binding	Datastore-BindingTargetStruct				M

Binding represents the binding to be added to the endpoint.

EndpointID represents the unique identifier for the endpoint to be updated in the [Joint Fabric](#) Datastore Cluster.

NodeID represents the unique identifier for the node to which the endpoint belongs.

Upon receipt of this command, the Datastore SHALL:

1. Confirm that an Endpoint Information Entry exists for the given NodeID and EndpointID, and if not, return NOT_FOUND.
2. Ensure the Binding List for the Node Information Entry with the given NodeID includes the given Binding. If it does not:
 - a. Add the Binding to the Binding List for the Node Information Entry for the given NodeID. The new entry's status SHALL be set to **Pending**.
 - b. Add this Binding to the given Node ID.
 - i. If this succeeds, update the new Binding in the Datastore to **Committed**.
 - ii. If not successful, update the Status to **CommitFailed** and the FailureCode to the returned error. The error SHALL be handled in a subsequent [Node Refresh](#).

11.24.7.18. RemoveBindingFromEndpointForNode Command

This command SHALL be used to remove a binding from an endpoint for a node in the [Joint Fabric](#) Datastore Cluster of the accessing fabric.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ListID	uint16	all			M
1	EndpointID	endpoint-no	all			M
2	NodeID	node-id	all			M

ListID represents the unique identifier for the binding entry in the Datastore's EndpointBindingList attribute to be removed from the endpoint.

EndpointID represents the unique identifier for the endpoint to be updated in the [Joint Fabric](#) Data-