

Check [ICAC Cross Signing](#) for details about the generation of the [ICACCSR](#).

ID	Name	Type	Constraint	Quality	Default	Conformance
0	ICACCSR	octstr	max 600			M

ICACCSR field

This field SHALL be a DER-encoded octet string of a properly encoded [PKCS #10](#) Certificate Signing Request (CSR).

11.25.7.3. AddICAC Command

This command SHALL be generated and executed during [Joint Commissioning Method](#) and subsequently be responded in the form of an [ICACResponse](#) command.

A Commissioner or Administrator SHALL issue this command after issuing the [ICACCSRRequest](#) command and receiving its response.

A Commissioner or Administrator SHALL issue this command after performing the Attestation Procedure, Fabric Table VID Verification and after validating that the peer is authorized to act as an Administrator in its own Fabric.

Check [ICA Cross Signing](#) for details about the generation of [ICACValue](#).

ID	Name	Type	Constraint	Quality	Default	Conformance
1	ICACValue	octstr	max 400			M

ICACValue Field

This field SHALL contain an [ICAC](#) encoded using [Matter Certificate Encoding](#).

Effect on Receipt

This command SHALL be received over a [CASE](#) session otherwise it SHALL fail with an INVALID_COMMAND status code.

If this command is received without an armed fail-safe context (see [Section 11.10.7.2, “ArmFail-Safe”](#)), then this command SHALL fail with a FAILSAFE_REQUIRED status code sent back to the initiator.

If a prior AddICAC command was successfully executed within the fail-safe timer period, then this command SHALL fail with a CONSTRAINT_ERROR status code sent back to the initiator.

Upon receipt, the ICACValue SHALL be validated in the following ways:

1. Verify the ICAC using [Crypto_VerifyChain\(certificates = \[ICACValue, RootCACertificate\]\)](#) where RootCACertificate is the associated RCAC of the [accessing fabric](#). If this check fails, the error status SHALL be InvalidICAC.