

2. The public key of the ICAC SHALL match the public key present in the last [ICACSRResponse](#) provided to the Administrator that sent the [AddICAC](#) command. If this check fails, the error status SHALL be InvalidPublicKey.
3. The [DN Encoding Rules](#) SHALL be validated for the ICAC. If this check fails, the error status SHALL be InvalidICAC.

If any of the above validation checks fail, the server SHALL immediately respond to the client with an [ICACResponse](#). The StatusCode field of the ICACResponse SHALL be set to the error status value specified in the above validation checks.

If all the checks succeed, then the ICACValue SHALL be used as described in the [Joint Commissioning Method](#).

11.25.7.4. ICACResponse Command

This command SHALL be generated in response to the [AddICAC](#) command.

ID	Name	Type	Constraint	Quality	Default	Conformance
0	StatusCode	ICACResponseStatusEnum				M

StatusCode Field

This field SHALL contain an [ICACResponseStatusEnum](#) value representing the status of the [AddICAC](#) operation.

11.25.7.5. OpenJointCommissioningWindow Command

NOTE

This is an alias onto the [OpenCommissioningWindow](#) command within the Joint Fabric Administrator Cluster. Refer to the [OpenCommissioningWindow](#) command for a description of the command behavior and parameters.

This command SHALL fail with a [InvalidAdministratorFabricIndex](#) status code sent back to the initiator if the [AdministratorFabricIndex](#) attribute has the value of null.

The parameters for OpenJointCommissioningWindow command are as follows:

ID	Name	Type	Constraint	Quality	Default	Conformance
0	Commissioning-Timeout	uint16	desc			M
1	PAKEPass-codeVerifier	octstr	97			M