

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0002	Max-ClientCertificates	uint8	2 to 254	F		R V	M
0x0003	Provisioned-ClientCertificates	list[TLSClientCertificateDetailStruct]	max Max-ClientCertificates	N		R V S	M

14.4.5.1. MaxRootCertificates Attribute

This attribute SHALL contain the maximum number of per fabric [TLSRCACs](#) that can be installed on this Node.

14.4.5.2. ProvisionedRootCertificates Attribute

This attribute SHALL be a list of all provisioned [TLSCertStruct](#) that are currently installed on this Node. When this attribute is read over a non [Large Message](#) capable transport, the Certificate field SHALL NOT be included. To get the full details of a certificate use the [FindRootCertificate](#) command.

14.4.5.3. MaxClientCertificates Attribute

This attribute SHALL contain the maximum number of per fabric [Client Certificates](#) that can be installed on this Node.

14.4.5.4. ProvisionedClientCertificates Attribute

This attribute SHALL be a list of all provisioned [TLSCCDID](#) that are currently installed on this Node. When this attribute is read over a non [Large Message](#) capable transport, the ClientCertificate and IntermediateCertificates fields SHALL NOT be included. To get the full details of a client certificate use the [FindClientCertificate](#) command.

14.4.6. Commands

ID	Name	Direction	Response	Access	Quality	Conformance
0x00	Provision-RootCertificate	client ⇒ server	Provision-RootCertificateResponse	A F	L	M
0x01	Provision-RootCertificateResponse	client ⇐ server	N		L	M