

- Generate a new [TLSCAID](#)
- Create and populate a [TLSCertStruct](#) with the generated TLSCAID and the passed in *Certificate* field, associated with the [accessing fabric](#)
- Add the resulting [TLSCertStruct](#) to the [ProvisionedRootCertificates](#) list.
- Else if the passed in *CAID* is not null:
 - If there is no matching entry found for the passed in *CAID* in the [ProvisionedRootCertificates](#) list:
 - Fail the command with the status code NOT_FOUND, and end processing with no other side effects.
 - If the [associated fabric](#) of that entry does not equal the [accessing fabric](#):
 - Fail the command with the status code NOT_FOUND, and end processing with no other side effects.
 - Update the [Certificate Field](#) field of that entry with the passed in *Certificate* field.
- Return the TLSCAID as the [CAID](#) field in the corresponding [ProvisionRootCertificateResponse](#) command.

Note when using this command for certificate rotation, the updated certificate will only be used for new underlying TLS connections established after this call.

14.4.6.2. ProvisionRootCertificateResponse Command

This command SHALL be generated in response to a ProvisionRootCertificate command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	CAID	TLSCAID	0 to 65534			M

CAID Field

This field SHALL be a [TLSCAID](#) representing the unique Certificate Authority ID.

14.4.6.3. FindRootCertificate Command

This command SHALL return the specified TLS root certificate, or all provisioned TLS root certificates for the [accessing fabric](#), based on the contents of the CAID field.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	CAID	TLSCAID	all	X		M

CAID Field

This field SHALL be a [TLSCAID](#) representing the unique Certificate Authority ID to return, or null to return all provisioned root certificates.