

)

- Return the CCDID as [CCDID](#), the DER-encoded `tls_csr` as [CSR](#), and `tls_nonce_signature` as [NonceSignature](#), in the corresponding [ClientCSRResponse](#) command.

14.4.6.9. ClientCSRResponse Command

This command SHALL be generated in response to a [ClientCSR](#) command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	CCDID	TLSCCDID	0 to 65534			M
1	CSR	octstr	max 3000			M
2	NonceSignature	octstr	max 128			M

CCDID Field

This field SHALL be a [TLSCCDID](#) representing the unique Client Certificate Details ID.

CSR Field

This field SHALL be a DER-encoded octet string of a [PKCS #10](#) format Certificate Signing Request.

NonceSignature Field

This field SHALL be an octet string of the [ec-signature](#) of the [Nonce](#) field from the corresponding [ClientCSR](#) command.

14.4.6.10. ProvisionClientCertificate Command

This command SHALL be generated to request the Node provisions newly provided Client Certificate Details, or rotate an existing client certificate.

This command is typically invoked after having created a new client certificate using the CSR requested in [ClientCSR](#), with the [TLSCCDID](#) returned by [ClientCSRResponse](#).

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	CCDID	TLSCCDID	0 to 65534			M
1	ClientCertificate	octstr	max 3000			M
2	IntermediateCertificates	list[octstr]	0 to 10 [max 3000]			M