

Value	Name	Summary
0x02	EndpointAlreadyInstalled	The endpoint is already installed.
0x03	RootCertificateNotFound	No root certificate exists for this CAID.
0x04	ClientCertificateNotFound	No client certificate exists for this CCDID.
0x05	EndpointInUse	The endpoint is in use and cannot be removed.
0x06	InvalidTime	Time sync has not yet occurred.

14.5.6. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	MaxProvisioned	uint8	5 to 254	F		R V	M
0x0001	ProvisionedEndpoints	list[TLSEndpointStruct]	desc	N		R V S	M

14.5.6.1. MaxProvisioned Attribute

This attribute SHALL indicate the maximum number of per fabric TLSEndpoints that can be installed on this Node.

14.5.6.2. ProvisionedEndpoints Attribute

This attribute SHALL indicate a list of currently provisioned TLS Endpoints on this Node. The maximum length of this list when read will be the value of [MaxProvisioned](#).

14.5.7. Commands

ID	Name	Direction	Response	Access	Quality	Conformance
0x00	ProvisionEndpoint	client ⇒ server	ProvisionEndpointResponse	A F	L	M
0x01	ProvisionEndpointResponse	client ⇐ server	N		L	M