

ID	Name	Direction	Response	Access	Quality	Conformance
0x02	FindEndpoint	client ⇒ server	FindEndpointResponse	O F	L	M
0x03	FindEndpointResponse	client ⇐ server	N		L	M
0x04	RemoveEndpoint	client ⇒ server	N	A F	L	M

14.5.7.1. ProvisionEndpoint Command

This command is used to provision a TLS Endpoint for the provided Hostname / Port combination.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0x00	Hostname	octstr	4 to 253			M
0x01	Port	uint16	1 to 65535			M
0x02	CAID	TLSCAID	0 to 65534			M
0x03	CCDID	TLSCCDID	all	X		M
0x04	EndpointID	TLSEndpointID	all	X		M

Hostname Field

This field SHALL represent a TLS Hostname.

Port Field

This field SHALL represent a TLS Port Number.

CAID Field

This field SHALL be the [TLSCAID](#) used to associate the [TLSRCAC](#) with this endpoint.

CCDID Field

This field SHALL be the [TLSCCDID](#) used to associate the Client Certificate Details with this endpoint. A NULL value means no client certificate is associated.

EndpointID Field

This field SHALL represent the unique TLS Endpoint. A NULL value causes a new endpoint to be created and a non-NULL value allows for updating an existing endpoint.