

4.3.9. Attributes	348
4.3.10. Commands	368
4.4. Fan Control Cluster	374
4.4.1. Revision History	374
4.4.2. Classification	374
4.4.3. Cluster ID	374
4.4.4. Features	375
4.4.5. Data Types	375
4.4.6. Attributes	377
4.4.7. Commands	384
4.5. Thermostat User Interface Configuration Cluster	385
4.5.1. Revision History	385
4.5.2. Classification	386
4.5.3. Cluster ID	386
4.5.4. Conversion of Temperature Values for Display	386
4.5.5. Data Types	386
4.5.6. Attributes	387
4.6. Valve Configuration and Control Cluster	388
4.6.1. Revision History	388
4.6.2. Classification	388
4.6.3. Cluster ID	388
4.6.4. Features	388
4.6.5. Data Types	389
4.6.6. Status Codes	390
4.6.7. Attributes	390
4.6.8. Commands	393
4.6.9. Events	395
5. Entry Control	397
5.1. General Description	397
5.1.1. Introduction	397
5.1.2. Cluster List	397
5.2. Door Lock Cluster	397
5.2.1. Revision History	398
5.2.2. Classification	398
5.2.3. Cluster ID	398
5.2.4. Features	399
5.2.5. Recommended steps for creating a new User	402
5.2.6. Data Types	402
5.2.7. Status Codes	419
5.2.8. PIN/RFID Code Format	420
5.2.9. Attributes	420