

ID	Cluster Name	Description
0x0080	Boolean State Configuration	Attributes and commands for configuration related to boolean state
0x0050	Mode Select	Allows a user to choose one mode option from several pre-defined values
n/a	Mode Base	Allows a user to choose one mode option from several pre-defined values
0x0508	Low Power	This cluster provides an interface for managing low power mode on a device.
0x0503	Wake On LAN	This cluster provides an interface for managing low power mode on a device that supports the Wake On LAN protocol.
0x003B	Switch	Attributes and events for various types of switch devices.
0x0060	Operational State	Commands and attributes for defining a device's operational state
n/a	Alarm Base	Base alarm cluster from which all alarms are derived
0x0097	Messages	Commands and attributes for sending messages to devices
0x0150	Service Area	Commands and attributes for controlling and querying the operating service areas of devices

1.2. Identify Cluster

This cluster supports an endpoint identification state (e.g., flashing a light), that indicates to an observer (e.g., an installer) which of several nodes and/or endpoints it is. It also supports a multi-cast request that any endpoint that is identifying itself to respond to the initiator.

The state of this cluster MAY be shared on more than one endpoint on a node.

For Example: Two endpoints on a single node, one a temperature sensor, and one a humidity sensor, may both share the same cluster instance and therefore identification state (e.g. single LED on the node).