

Value	Name	Summary	Conformance
0x00	Default	Indicates the default effect is used	M

1.2.5. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Identify-Time	uint16	all	Q		RW VO	M
0x0001	Identify-Type	Identify-TypeEnum	desc			R V	M

1.2.5.1. IdentifyTime Attribute

This attribute SHALL represent the remaining length of time, in seconds, that the endpoint will continue to identify itself.

If this attribute is set to a value other than 0 then the device SHALL enter its identification state, in order to indicate to an observer which of several nodes and/or endpoints it is. It is RECOMMENDED that this state consists of flashing a light with a period of 0.5 seconds. The IdentifyTime attribute SHALL be decremented every second while in this state.

If this attribute reaches or is set to the value 0 then the device SHALL terminate its identification state.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- When it changes from 0 to any other value and vice versa, or
- When it is written by a client, or
- When the value is set by an Identify command.

Since this attribute is not being reported during a regular countdown, clients SHOULD NOT rely on the reporting of this attribute in order to keep track of the remaining duration.

1.2.5.2. IdentifyType Attribute

This attribute SHALL indicate how the identification state is presented to the user.

This attribute SHALL contain one of the values defined in [IdentifyTypeEnum](#). The value None SHALL NOT be used if the device is capable of presenting its identification state using one of the other methods defined in [IdentifyTypeEnum](#).

1.2.6. Commands