

1.4.7.1. CopyModeBitmap Type

This data type is derived from map8.

Bit	Name	Summary	Conformance
0	CopyAllScenes	Copy all scenes in the scene table	M

1.4.7.2. SceneInfoStruct Type

Access Modifier: Fabric Scoped							
ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	SceneCount	uint8	all				M
1	CurrentScene	uint8	desc			S	M
2	CurrentGroup	group-id	all			S	M
3	SceneValid	bool	all			S	M
4	RemainingCapacity	uint8	max 253				M

1.4.7.2.1. SceneCount Field

This field SHALL indicate the number of scenes currently used in the server's Scene Table on the endpoint where the Scenes Management cluster appears.

This only includes the count for the associated fabric.

1.4.7.2.2. CurrentScene Field

This field SHALL indicate the scene identifier of the scene last invoked on the associated fabric. If no scene has been invoked, the value of this field SHALL be 0xFF, the undefined scene identifier.

1.4.7.2.3. CurrentGroup Field

This field SHALL indicate the group identifier of the scene last invoked on the associated fabric, or 0 if the scene last invoked is not associated with a group.

1.4.7.2.4. SceneValid Field

This field SHALL indicate whether the state of the server corresponds to that associated with the CurrentScene and CurrentGroup fields of the SceneInfoStruct they belong to. TRUE indicates that these fields are valid, FALSE indicates that they are not valid.