

- RESOURCE_EXHAUSTED and the server continues from step 5.
4. The server adds the scene entry into its Scene Table with fields copied from the AddScene command data fields and the status SHALL be SUCCESS.
 - a. Any ExtensionFieldSetStruct referencing a ClusterID that is not implemented on the endpoint MAY be omitted during processing.
 - b. Any AttributeValuePairStruct referencing an AttributeID from the referenced cluster that is not implemented on the endpoint MAY be omitted during processing.
 - c. If the ExtensionFieldSetStructs list has multiple entries listing the same ClusterID, the last one within the list SHALL be the one recorded.
 - d. Within a single entry of the ExtensionFieldSetStructs list, if an ExtensionFieldSet contains the same AttributeID more than once, the last one within the ExtensionFieldSet SHALL be the one recorded.
 5. If the AddScene command was received as a unicast, the server SHALL then generate an AddSceneResponse command with the Status field set to the evaluated status.

The SceneTransitionTime field of the Scene Table SHALL be updated with the value of the TransitionTime.

1.4.9.3. AddSceneResponse Command

This command is sent in response to the [AddScene](#) command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	status	desc			M
1	GroupID	group-id	all			M
2	SceneID	uint8	max 254			M

1.4.9.3.1. Status Field

This field SHALL be set according to the Effect on Receipt section for [AddScene](#) command.

1.4.9.3.2. GroupID Field

The GroupID field SHALL be set to the corresponding field of the received [AddScene](#) command.

1.4.9.3.3. SceneID Field

The SceneID field SHALL be set to the corresponding field of the received [AddScene](#) command.

1.4.9.3.4. When Generated

This command is generated in response to a received [AddScene](#) command.

1.4.9.4. ViewScene Command

This command returns the details for the requested scene.